




Microwave Oven

Owner's Manual

MW610WA / MW610WB
MW620WA / MW620WB
MW630WA / MW630WB



Safety	2
Your New Microwave oven.....	5
Checking Parts	5
Thank You for Choosing Samsung	5
Setting Up Your Microwave Oven	5
Operation Guide	6
MW610WA / MW610WB Operation Check	6
Features & Control	6
MW620WA / MW620WB	7
Operation Check	7
Variable Power Cooking Chart	7
MW630WA / MW630WB	8
Control Panel Buttons	8
Function of Touch Pads(MW630WA/MW630WB)	9
Using the One Minute+ Button	9
Clock Set	10
Defrosting(MW630WA/MW620WB)	11
Time Cooking(MW630WA/MW620WB)	11
One Stage Programming	11
Two Stage Programming	12
Start(MW630WA/MW620WB)	12
Pause/Cancel(MW630WA/MW620WB)	12
How to Correct Programming Errors	12
Cleaning & Care	13
Cooking Instructions	14
Cooking Utensils	14
Testing Utensils	14
Cooking Techniques	15
General Tips	15
Cooking Guide	16
Defrosting Guide(MW620WA/MW620WB/MW630WA/MW630WB)	18
Recipes	19
Appendix.....	21
Troubleshooting Guide	21
Care and Cleaning	21
Specifications	22
Manual Blok Warranty Card	Inside Back Cover
Quick Reference(MW630WA/MW630WB)	Back Cover

Safety

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY:

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the front face of the oven and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the
 - 1) Door (bent or dented),
 - 2) Hinges and latches (broken or loosened),
 - 3) Door seals and sealing surfaces.
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

WARNING

Always observe Safety Precautions when using your oven. Never try to repair the oven on your own – there is dangerous voltage inside. If the oven needs to be repaired, call 1-800-SAMSUNG for the name of an authorized service center near you.

IMPORTANT SAFETY INSTRUCTIONS

When using any electrical appliance, basic safety precautions should be followed, including the following:

WARNING

To reduce risk of burns, electric shock, fire, personal injury or exposure to excessive microwave energy:

- Read all safety instructions before using the appliance.
- Read and follow the specific “Precautions to Avoid Possible Exposure to Excessive Microwave Energy” on this page.
- This appliance must be grounded. Connect only to properly grounded outlets. See “Important Grounding Instructions” on page 4 of this manual.
- Install or place this appliance only in accordance with the installation instructions provided.
- Some items, like whole eggs and food in sealed containers, may explode if heated in this oven.
- Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook, or dry food. It is not designed for industrial or laboratory use.
- As with any appliance, close supervision is necessary when used by children.
- Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged.
- This appliance should be serviced only by qualified service personnel. Contact the nearest authorized service facility for examination, repair, or adjustment.
- Do not cover or block any of the openings on this appliance.

SAVE THESE INSTRUCTIONS

Safety

Important Safety Instructions, continued

- Do not store this appliance outdoors. Do not use near water – for example, near a kitchen sink, in a wet basement, or near a swimming pool, etc.
- Keep the inside of the oven clean. Food particles or spattered oils stuck to the oven walls or floor can cause paint damage and reduce the efficiency of the oven.
- Do not immerse cord or plug in water.
- Keep cord away from heated surfaces.
- Do not let cord hang over edge of table or counter.
- When cleaning door and oven surfaces, use only mild, nonabrasive soaps or detergents applied with a sponge or soft cloth.
- To reduce the risk of fire in the oven:
 - a. Do not overcook food. Watch appliance carefully if paper, plastic, or other combustible materials are inside.
 - b. Remove wire twist-ties from plastic cooking bags before placing bags in oven.
 - c. If materials inside the oven ignite, keep the oven door closed, turn the oven off, disconnect the power cord, or shut off the power at the fuse or circuit breaker panel.
 - d. Do not use the oven compartment for storage purposes. Do not leave paper products, cooking utensils, or food in the oven when not in use.
- Do not try to preheat oven or operate while empty.
- Do not cook without the glass tray in place on the oven floor. Food will not cook properly without the tray.
- Do not defrost frozen beverages in narrow-necked bottles. The containers can break.
- Dishes and containers can become hot. Handle with care.
- Carefully remove container coverings, directing steam away from hands and face.
- Remove lids from baby food before reheating. After heating baby food, stir well and test temperature by tasting before serving.
- A short power-supply cord is provided to reduce the risk of becoming entangled in or tripping over a longer cord. Longer cord sets or extension cords are available and may be used with caution.
- Do not operate any other heating or cooking appliance beneath this appliance.
- Do not mount unit over or near any portion of a heating or cooking appliance.
- Do not mount over a sink.
- Do not store anything directly on top of the appliance when it is in operation.

SAVE THESE INSTRUCTIONS

Safety

IMPORTANT GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electrical current. This appliance is equipped with a cord that includes a grounding wire and a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded. Plug the three-prong power cord into a properly grounded outlet of standard 115-120 voltage, 60 Hz. Your oven should be the only appliance on this circuit.

WARNING

Improper use of the grounding plug can result in a risk of electric shock. Consult a qualified electrician or servicer if you do not understand the grounding instructions or if you are not sure if the appliance is properly grounded.

Use of Extension Cords

A short power-supply cord is provided to reduce the risk of becoming entangled in or tripping over a longer cord. Longer cord sets or extension cords are available and may be used if care is exercised in their use. If a long cord or extension cord is used:

1. The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
2. The extension cord must be a grounding-type 3- wire cord and it must be plugged into a 3-slot outlet.
3. The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over accidentally. If you use an extension cord, the interior light may flicker and the blower may vary when the microwave oven is on. Cooking times may be longer, too.

WARNING


Do not cut or remove the third (ground) prong from the power cord under any circumstances.

SAVE THESE INSTRUCTIONS

Your New Microwave oven

Checking Parts

Unpack your microwave oven and check to make sure that you have all the parts shown here. If any part is missing or broken, call your dealer.



microwave oven



roller guide ring



instruction manual



glass tray



registration card

Thank You for Choosing Samsung

Your new oven represents the latest in microwave cooking technology. This oven is a full-featured, easy-to-use appliance built to strict quality standards set by Samsung — the highest in the industry. We're proud to offer you a product that will provide convenient, dependable service for years to come.

Please record the serial number from the inside or back of your Samsung microwave oven and the date of purchase in the space provided below. We recommend that you keep your purchase receipt with this manual for easy warranty service.

Model Number _____
Serial Number _____
Date Purchased _____
Dealer _____

Setting Up Your Microwave Oven


- 1 Place the oven on a flat, sturdy surface and plug the cord into a grounded outlet. Once plugged in, the display on your oven will show:




(MW630WA, MW630WB)

Make sure there is adequate ventilation for your oven by leaving at least four inches of space behind, above, and to the side of the oven.

- 2 Open the oven door by pressing the button below the control panel.
- 3 Wipe the inside of the oven with a damp cloth.
- 4 Place the pre-assembled ring in the indentation in the center of the oven.



- 5 Place the glass tray on top of the ring so that the three glass tabs in the center of the tray fit securely into the tabs on the floor of the oven.



Operation Guide


MW610WA / MW610WB Operation Check

- 1** Plug the microwave oven into an AC outlet.
- 2** Open the door and place the food in the oven.
- 3** Set the Timer for required time. (Oven lamp turns on)
- 4** Close the door. (Microwave cooking starts and Turntable rotates.)


NOTE1

1. When cooking time is less than 2 minutes, first, turn the knob past the 2 minute mark, then return the knob to the time you want.
2. When the cooking period is completed, the oven will turn off automatically.

Features & Control




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Oven Lamp 2. Ventilation Openings 3. Timer (15 minutes Timer) 4. Door Open Button | <ol style="list-style-type: none"> 5. Door Latches & Safety Interlocks 6. Oven Door with see-through window 7. Glass Tray (Turntable) & Roller Guide |
|---|---|



Operation Guide

MW620WA / MW620WB



Operation Check

- 1 Plug the microwave oven into an AC outlet.
- 2 Open the door and place the food in the oven.
- 3 Set the Timer for required time. (oven lamp turns on)
- 4 Turn the **Power Control knob** to desired power level : Warm, Defrost, Medium, Med-High, or High.
- 5 Close the door.
(Microwave cooking starts and Turntable rotates.)

NOTE1

1. When cooking time is less than 2 minutes, first, turn the knob past the 2 minute mark, then return the knob to the time you want.
2. When the cooking period is completed, the oven will turn off automatically.

• Variable Power Cooking Chart


The Variable Cooking Control allows you to select the amount of microwave energy and the rate of cooking/defrosting. There are 5 preset power levels.

Power Level	Percentage
HIGH	100% / 600W
MED-HIGH	70% / 420W
MEDIUM	50% / 300W
DEFROST	30% / 180W
WARM	10% / 60W

Operation Guide

MW630WA / MW630WB

Control Panel Buttons



- 1. Defrost** **page 11**
Press to set the defrosting time of the food to be defrosted.
- 2. One Minute+** **page 9**
Press once for every minute of cooking at High power.
- 3. Number buttons**
Sets cooking times or amounts and power levels other than high.
- 4. Power level** **page 9**
Sets power to level other than high.
- 5. Clock** **page 10**
Sets current time.
- 6. Pause/Cancel** **page 12**
Press to pause oven or correct a mistake.
- 7. Start** **page 12**
Press to start cooking.

Operation Guide

Function of Touch Pads(MW630WA/MW630WB)

The touch pads on the control panel provide the means to program the oven for its specific cooking operations. Each pad and its function is described briefly as follows:

Power Level Pad — Used for selection of power levels (10-Hi) in the cooking operations.

There are ten power levels as indicated in the chart below.

Pad	Touch	Display	Output	Level Name
Power Level	Once	PL:Hi	600W	High
	Twice	PL:90	540W	Sauté
	3 Times	PL:80	480W	Reheat
	4 Times	PL:70	420W	Medium High
	5 Times	PL:60	360W	Simmer
	6 Times	PL:50	300W	Medium
	7 Times	PL:40	240W	Medium Low
	8 Times	PL:30	180W	Defrost
	9 Times	PL:20	120W	Low
	10 Times	PL:10	60W	Warm

Clock — Used to set clock with the time of day and to reset the clock if needed.

Number Pads — Used to set the clock, and to enter the desired cooking time and the defrosting time.

Defrost Pad — Used to thaw frozen food.

The defrost power level is 30 percent of HIGH power.

Pause/Cancel Pad — Stops and clears all cooking operations and programs except Clock.

Start Pad — Used to start operation of the oven.

NOTE

1. When programming instructions into the oven, a short beep tone will be heard. If a pad is touched and a beep tone is not heard, the oven has not or cannot accept the instructions.
2. When the oven finishes a complete cooking program the oven will automatically shut off and four beeps will sound.

Using the One Minute+ Button

This button offers a convenient way to heat food in one-minute increments at the High power level.

- 1 Press the **One Minute+** button once for each minute you wish to cook the food.

For example, press it twice for two minutes. The time will display, and the oven starts automatically.

*Add minutes to a program in progress by pressing the **One Minute+** button for each minute you want to add.*

Operation Guide

Clock Set

- 1 Plug into the wall receptacle.
Display window will show "88:88".



- 2 Touch **CLOCK**.
Display window will show "0".



- 3 Enter the time of day by touching the number pads in sequence.
For example, to set 12:59 (am or pm), touch the number pads 1, 2, 5, and 9. Display window shows "12 59" without colon.



- 4 Touch **CLOCK**.
Colon appears and the time of day will be displayed as long as the power cord is plugged in.



NOTE

1. To reset time of day on the display window, push the **CLOCK** pad. The number "0" will appear without colon.
2. The time between 00:00 and 00:59 is impossible to set.
3. If you want to modify the time before setting, touch the **Pause/Cancel** pad.
4. You can check the current time while cooking is in progress by pressing the **Clock** button.

Operation Guide

Defrosting(MW630WA/MW620WB)

The defrost setting is designed for speedy thawing of frozen food and is one of the great advantages of a microwave oven.

- Power Level 30 is automatically set for defrosting.

1 Place frozen food in the oven and close the door.

2 Touch **Defrost**.
Display window shows PL:30.



3 Enter defrosting time (up to 99 min. 99 sec.) by touching the number pads.

For example, to set 5 minutes 35 seconds, touch 5, 3 and 5 in sequence. Display window shows "5:35".



4 Touch **Start**.
Defrosting time counts down and defrosting begins. When defrosting is completed, the oven beeps four times and shuts off automatically, then the time of day will reappear on the display window.

See page 18 for the Defrosting Guide.

Time Cooking(MW630WA/MW630WB)

One Stage Programming

1 Touch **Power Level**. Select one of the ten Power Levels by touching the **Power Level** pad. For example, to set PL:50, touch the **Power Level** pad 6 times. When you touch the **Power Level** pad repeatedly, Power Level decreases at the rate of 10 percent of HIGH power.



2 Enter cooking time (up to 99 min. 99 sec.) by touching the number pads. For example, to set 5 minutes 30 seconds, touch 5, 3 and 0 in sequence. Display window shows "5:30".



3 Touch **Start**. Cooking time counts down and cooking begins. When cooking finishes the oven beeps four times and shuts off automatically, then the time of day will reappear on the display window.

Operation Guide

Two Stage Programming

- 1** Touch **Defrost**.
Display window shows "PL:30".




- 2** Enter defrosting time (up to 99 min. 99 sec.) by touching the number pads. For example, to set 3 minutes 50 seconds, touch 3, 5 and 0 in sequence. Display window shows "3:50".



- 3** Touch **Power Level**. For example, to set PL:Hi, touch the **Power Level** pad once. Display window shows "PL:Hi".



- 4** Enter cooking time (up to 99 min. 99 sec.) by touching the number pads.
For example, to set 4 minutes 50 seconds, touch 4, 5 and 0 in sequence. Display window shows "4:50".



Time Cooking can't

- 5** Touch **Start**.
The first stage defrosting time appears in the display window and counts down. As soon as the defrosting finishes, the second stage cooking time appears automatically and counts down.

Start(MW630WA/MW630WB)

One touch allows the oven to begin.

If the door is opened while the oven is operating, the cooking will pause. The **Start** pad must be touched again to continue the cooking operation after the door is closed.

Pause/Cancel(MW630WA/MW630WB)

Use the **Pause/Cancel** pad to:

1. Erase if you make a mistake during programming.
2. Cancel the minute timer.
3. Stop the oven temporarily during cooking.
4. To cancel a program during cooking, touch twice.

How to Correct Programming Errors

Mistakes made when entering program information can be corrected by touching the **Pause/Cancel** pad and then re-entering the correct program.

NOTE

A cooking program entered in one stage can not be changed after you have started to enter the program for the next stage. To correct, the **Pause/Cancel** pad must be touched and all cooking instructions re-entered beginning with the first stage.

No changes in programs can be made after the oven has started operating. To make a change you must touch the **Pause/Cancel** pad and re-program the entire sequence. When making changes in this manner be careful to take into account the cooking time already elapsed in the old program before entering the new program.

Operation Guide

Cleaning & Care

1. Do not attempt to tamper with or make any adjustments or repairs to the door control panel, safety interlock switches, or any other part of the oven. Repairs should only be done by a qualified service person.
2. Keep the inside of the oven clean. Food particles or spilled liquids stick to oven walls and in-between seal and door surfaces. This material will absorb microwaves and reduce the efficiency of the oven.

Wipe up all spills with a damp cloth. Mild detergent may be used if the oven gets very dirty. Do not use harsh detergents or abrasives.

TIP: To help loosen baked on food particles or spilled liquids, heat 2 cups of water in a 4-cup measuring glass at HIGH(Hi) power for 5 minutes or until boiling. Let stand in oven 1 to 2 minutes. To keep the oven fresh smelling, add the juice of one lemon to the water before placing in oven.

3. It is occasionally necessary to remove the glass tray for cleaning of the tray or oven. To prevent breakage, do not place tray into water just after cooking. The tray is heavy and can be broken if dropped. Wash it carefully in warm, sudsy water or in dishwasher.

4. The outside surface of the oven should be cleaned occasionally with soap and a damp cloth, rinsed, and dried with a soft cloth. To prevent damage to the operating parts inside the oven, water should not be allowed to seep into the ventilation openings.
5. The door window should be washed with very mild soap and water. Be sure to use a soft cloth to avoid scratching.
6. If steam accumulates inside or around the outside of the oven door, wipe with a soft cloth to remove. This condition may occur when oven is operated during periods of high humidity and in no way indicates microwave leakage.
7. Wipe off immediately anything spilled in the oven to avoid the possibility of staining.
8. Do not cook directly (use proper cooking utensil) on the glass tray unless indicated in the cooking guide.
9. Never operate the oven without food or water in it as this may result in damage to the magnetron tube or energy-absorbing glass tray. A cup of water left in the oven when it is not in use will safely absorb this energy if the oven is accidentally turned on.

Cooking Instructions

Cooking Utensils

Recommended Use

- **Glass and glass-ceramic bowls and dishes** — Use for heating or cooking.
- **Microwave browning dish** — Use to brown the exterior of small items such as steaks, chops, or pancakes. Follow the directions provided with your browning dish.
- **Microwavable plastic wrap** — Use to retain steam. Leave a small opening for some steam to escape and avoid placing it directly on the food.
- **Wax paper** — Use as a cover to prevent spattering.
- **Paper towels and napkins** — Use for short-term heating and covering; they absorb excess moisture and prevent spattering. Do not use recycled paper towels, which may contain metal and can catch fire.
- **Paper plates and cups** — Use for short-term heating at low temperatures. Do not use recycled paper, which may contain metal and can catch fire.
- **Thermometers** — Use only those labeled "Microwave Safe" and follow all directions. Check the food in several places. Conventional thermometers may be used once the food has been removed from the oven.

Limited Use

- **Aluminum foil** — Use narrow strips of foil to prevent overcooking of exposed areas. Using too much foil can damage your oven, so be careful.
- **Ceramic, porcelain, and stoneware** — Use these if they are labeled "Microwave Safe." If they are not labeled, test them to make sure they can be used safely. Never use dishes with metallic trim.
- **Plastic** — Use only if labeled "Microwave Safe." Other plastics can melt.
- **Straw, wicker, and wood** — Use only for short-term heating, as they can be flammable.


Not Recommended

- **Glass jars and bottles** — Regular glass is too thin to be used in a microwave, and can shatter.
- **Paper bags** — These are a fire hazard, except for popcorn bags that are designed for microwave use.
- **Styrofoam plates and cups** — These can melt and leave an unhealthy residue on food.
- **Plastic storage and food containers** — Containers such as margarine tubs can melt in the microwave.
- **Metal utensils** — These can damage your oven. Remove all metal before cooking.

Testing Utensils

If you are not sure whether a dish is microwave-safe or not, you can perform this test:

- 1 Fill a 1 cup glass measuring cup with water and put it inside your oven, next to the dish you want to test.



- 2 Press the **One Minute+** button once to heat them for one minute at High power.

The water should be warm and the dish you are testing should be cool. If the dish is warm, then it is absorbing microwave energy and is not acceptable for use in the microwave.

Cooking Instructions

Cooking Techniques

Stirring

Stir foods such as casseroles and vegetables while cooking to distribute heat evenly. Food at the outside of the dish absorbs more energy and heats more quickly, so stir from the outside to the center. The oven will turn off when you open the door to stir your food.

Arrangement

Arrange unevenly shaped foods, such as chicken pieces or chops, with the thicker, meatier parts toward the outside of the turntable where they receive more microwave energy. To prevent overcooking, place thin or delicate parts toward the center of the turntable.

Shielding

Shield food with narrow strips of aluminum foil to prevent overcooking. Areas that need shielding include poultry wing-tips, the ends of poultry legs, and corners of square baking dishes. Use only small amounts of aluminum foil. Larger amounts can damage your oven.

Turning

Turn foods over midway through cooking to expose all parts to microwave energy. This is especially important with large items such as roasts.

Standing

Foods cooked in the microwave build up internal heat and continue to cook for a few minutes after the oven stops. Let foods stand to complete cooking, especially foods such as roasts and whole vegetables. Roasts need this time to complete cooking in the center without overcooking the outer areas. All liquids, such as soup or hot chocolate, should be shaken or stirred when cooking is complete. Let liquids stand a moment before serving. When heating baby food, stir well and test the temperature before serving.

Adding Moisture

Microwave energy is attracted to water molecules. Food that is uneven in moisture content should be covered or allowed to stand so that the heat disperses evenly. Add a small amount of water to dry food to help it cook.

General Tips

- Dense foods, such as potatoes, take longer to heat than lighter foods. Foods with a delicate texture should be heated at a low power level to avoid becoming tough.
- Altitude and the type of cookware you are using can affect cooking time. When using a new recipe, use the minimum cooking time and check the food occasionally to prevent overcooking.
- Foods with a non-porous skin or shell, such as potatoes, eggs, or hot dogs, should be pierced to prevent bursting.
- Frying with heating oil or fat is not recommended. Fat and oil can suddenly boil over and cause severe burns.
- Some ingredients heat faster than others. For example, the jelly inside a jelly doughnut will be hotter than the dough. Keep this in mind to avoid burns.
- Home canning in the microwave oven is not recommended because all harmful bacteria may not be destroyed by the microwave heating process.
- Although microwaves do not heat the cookware, the heat is often transferred to the cookware. Always use pot holders when removing food from the microwave and instruct children to do the same.

Cooking Instructions

Cooking Guide

Guide for Cooking Meat in Your Microwave

- Place meat on a microwave-safe roasting rack in a microwave-safe dish.
- Start meat fat-side down. Use narrow strips of aluminum foil to shield any bone tips or thin meat areas.
- Check the temperature in several places before letting the meat stand the recommended time.
- The following temperatures are removal temperatures. The temperature of the food will rise during the standing time.

Food	Cook Time/Power Level	Directions
Roast Beef Boneless Up to 4 lbs.	<i>Cooking Time:</i> 7-10 min. / lbs. for 115° F - Rare 8-11 min. / lbs. for 120° F - Medium 9-14 min. / lbs. for 145° F - Well Done <i>Power Level:</i> High(Hi) for first 5 min., then Medium(50).	Place roast fat-side down on roasting rack. Cover with wax paper. Turn over when cooking time is half up. Let stand 10 min.
Pork Boneless or bone-in Up to 4 lbs.	<i>Cooking Time:</i> 18-20 min. / lbs. for 160° F Well Done <i>Power Level:</i> High(Hi) for first 5 min., then Medium(50).	Place roast fat-side down on roasting rack. Cover with vented plastic wrap. Turn over when cooking time is half up. Let stand 10 min.
Bacon 2-6 slices	<i>Cooking Time:</i> 2 slices: 1½- 2 min. 4 slices: 2½- 3½ min. 6 slices: 4-5½ min. <i>Power Level:</i> High(Hi).	Arrange slices on roasting rack or a dish lined with paper-towel. Cover with paper towel. Microwave until crisp.

Guide for Cooking Poultry in Your Microwave

- Place poultry on a microwave-safe roasting rack in a microwave-safe dish.
- Cover poultry with wax paper to prevent spattering.
- Use aluminum foil to shield bone tips, thin meat areas, or areas that start to overcook.
- Check the temperature in several places before letting the poultry stand the recommended time.

Food	Cook Time/Power Level	Directions
Whole Chicken Up to 4 lbs.	<i>Cooking Time:</i> 7-10 min. / lbs. 170° - 180°F <i>Power Level:</i> Medium High(Hi).	Place chicken breast-side down on roasting rack. Cover with wax paper. Turn over when the cooking time is half up. Cook until juices run clear and meat near the bone is no longer pink. Let stand 5-10 min.
Chicken Pieces Up to 2 lbs.	<i>Cooking Time:</i> 7-10 min. / lbs. 180°F dark meat 170°F light meat <i>Power Level:</i> Medium High(Hi).	Place chicken bone-side down on dish, with the thickest portions towards the outside of the dish. Cover with wax paper. Turn over when the cooking time is half up. Cook until juices run clear and meat near the bone is no longer pink. Let stand 5-10 min.

Cooking Instructions

Guide for Cooking Seafood in Your Microwave

- Cook fish until it flakes easily with a fork.
- Place fish on a microwave-safe roasting rack in a microwave-safe dish.
- Use a tight cover to steam fish. A lighter cover of wax paper or paper towel provides less steaming.
- Do not overcook fish; check it at minimum cooking time.

Food	Cook Time/Power Level	Directions
Steaks Up to 1.5 lbs.	<i>Cooking Time:</i> 6-8 min. / lbs. <i>Power Level:</i> Medium-High(70).	Arrange steaks on roasting rack with meaty portions towards the outside of rack. Cover with wax paper. Turn over and rearrange when cooking time is half up. Cook until fish flakes easily with a fork. Let stand 3-5 min.
Fillets Up to 1.5 lbs.	<i>Cooking Time:</i> 4-6 min. / lbs <i>Power Level:</i> High(Hi).	Arrange fillets in a baking dish, turning any thin pieces under. Cover with wax paper. If over ½ inch thick, turn over and rearrange when cooking time is half up. Cook until fish flakes easily with a fork. Let stand 2-3 min.
Shrimp Up to 1.5 lbs.	<i>Cooking Time:</i> 3-5 ½ min. / lbs. <i>Power Level:</i> High(Hi).	Arrange shrimp in a baking dish without overlapping or layering. Cover with wax paper. Cook until firm and opaque, stirring 2 or 3 times. Let stand 5 min.

Guide for Cooking Eggs in Your Microwave

- Never cook eggs in the shell, and never warm hard-cooked eggs in the shell; they can explode.
- Always pierce whole eggs to keep them from bursting.
- Cook eggs just until set; they become tough if overcooked.

Guide for Cooking Vegetables in Your Microwave

- Vegetables should be washed just before cooking. Often, no extra water is needed. If dense vegetables such as potatoes, carrots and green beans are being cooked, add about ¼ cup water.
- Small vegetables (sliced carrots, peas, lima beans, etc.) will cook faster than larger ones.
- Whole vegetables, such as potatoes, acorn squash or corn on the cob, should be arranged in a circle on the turntable before cooking. They will cook more evenly if turned over after half the cooking time.
- Always place vegetables like asparagus and broccoli with the stem ends pointing towards the edge of the dish and the tips toward the center.
- When cooking cut vegetables, always cover the dish with a lid or vented microwavable plastic wrap.
- Whole, unpeeled vegetables such as potatoes, squash, eggplant, etc., should have their skin pricked in several spots before cooking to prevent them from bursting.
- For more even cooking, stir or rearrange whole vegetables halfway through the cooking time.
- Generally, the denser the food, the longer the standing time. (Standing time refers to the time necessary for dense, large foods and vegetables to finish cooking after they come out of the oven.) A baked potato can stand on the counter for five minutes before cooking is completed, while a dish of peas can be served immediately.

Cooking Instructions

Defrosting Guide(MW620WA/MW620WB/ MW630WA/MW630WB)

- Unwrap food. Place food on microwave-safe rack, plate or shallow dish.
- After first half of defrosting time: remove any remaining wrap, break food apart or separate pieces if possible, remove any thawed food, if possible, shield tips, thin meat or warm areas of food with foil.
- When defrosted, food should be cool, but softened in all areas. If still slightly icy, return to microwave oven very briefly, or let stand a few minutes.
- Poultry and fish may be pacted under running cool water until defrosted.

Food	Microwave Time Defrost Level	Directions
Beef		
Chuck Roast Up to 5.0 lbs.	<i>Microwave Time: 7-9 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until a wooden pick can be easily inserted in center. Turn over twice.
Steaks up to 5 lbs	<i>Microwave Time: 6-9 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until pliable, then separate steaks and rearrange. Turn over twice.
Ground Beef up to 3 lbs	<i>Microwave Time: 8-10 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until pliable, then break apart and remove defrosted portions at halftime. Turn over twice.
Pork		
Spareribs Up to 3 lbs.	<i>Microwave Time: 6-8 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until pliable, then separate and rearrange. Turn over twice.
Pork Chops up to 3 lbs	<i>Microwave Time: 6-8 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until pliable, then separate and rearrange. Turn over twice.
Poultry		
Whole Chicken Up to 5 lbs.	<i>Microwave Time: 7-9 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until pliable, then break apart and rearrange portions at half time. Rinse cavity with cool water. Remove giblets.
Pieces up to 2 lbs	<i>Microwave Time: 9-11 min. / lb.</i> <i>Let Stand:5-10 min</i>	Place on plate or rack. Microwave until pliable, then break apart and rearrange portions at half time.
Seafood		
Steaks Up to 3-5 lbs.	<i>Microwave Time: 6-9 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until a wooden pick can be easily inserted in center, break apart and rearrange at half time.
Filletts up to 3-5 lbs	<i>Microwave Time: 4-7 min. / lb.</i> <i>Let Stand:5-10 min.</i>	Place on plate or rack. Microwave until a wooden pick can be easily inserted in center, break apart and rearrange at half time.
Shrimp up to 3 lbs	<i>Microwave Time: 4-7 min. / lb.</i> <i>Let Stand:5-10 min</i>	Place on plate or rack. Microwave until pliable, then separate and rearrange at half time.

Cooking Instructions

Recipes

Beef and Barley Stew

- 1½ lbs. beef stew cubes, cut into ½-inch pieces
- ½ cup chopped onion
- 2 Tbs. all-purpose flour
- 1 Tbs Worcestershire sauce
- 1 can (13.75-14.5 oz.) beef broth
- 2 medium carrots, cut into ½-inch slices (about 1 cup)
- ½ cup barley
- 1 bay leaf
- ¼ tsp. pepper
- 1 pkg. (9-10 oz.) frozen peas, thawed

1. In a 2-quart casserole, combine beef, onion, flour, and Worcestershire; mix well. Cover with lid. Cook at High for 6 to 8 minutes until beef is no longer pink, stirring once.
2. Stir in beef broth, carrots, barley, bay leaf, and pepper. Cover with lid. Cook at Medium for 45 to 50 minutes until carrots and beef are tender, stirring 2 to 3 times.
3. Stir in peas. Cover with lid. Cook at Medium for 10 minutes. Let stand for 10 minutes. Remove bay leaf before serving. *Makes 6 servings.*

Broccoli and Cheese Casserole

- ¼ cup butter or margarine
- ¼ cup chopped onion
- 1½ Tbs. flour
- ½ tsp. salt
- ¼ tsp. dry mustard
- ⅛ tsp. pepper
- 1½ cups milk
- ¼ cup chopped red pepper
- 8 oz. (2 cups) cheddar cheese, shredded
- 1 pkg. (9-10 oz.) frozen chopped broccoli, thawed
- 4 cups cooked spiral shaped pasta (8 oz. dry)

1. In a 2-quart casserole, cook butter and onion at High for 2 to 3 minutes until onion is soft, stirring once.
2. Add flour, salt, mustard, and pepper; mix well. Cook at High for 60 to 90 seconds until mixture boils. Stir in milk until smooth.
- 3. Stir in red pepper. Cook at High for 2 to 3 minutes until mixture boils and thickens slightly, stirring twice. Stir in cheese until melted.
4. Add broccoli and pasta, mix well. Cover with lid. Cook at High for 4 to 6 minutes until heated through, stirring once. Stir before serving. *Makes 6 servings.*

Cooking Instructions

Warm Potato Salad

2 lbs. small red potatoes, cut into ½-inch pieces
4 slices bacon (uncooked), cut into ½-inch pieces
¼ cup chopped onion
2 tsp. sugar
1 tsp. salt
1 tsp. flour
½ tsp. celery seed
⅛ tsp. pepper
2½ Tbs. apple cider vinegar

1. In a 2-quart casserole, combine potatoes and ¼ cup water. Cover with lid. Cook at High until potatoes are tender (10-12 min.); stir twice. Drain and set aside to cool slightly.
2. In a medium bowl, cook bacon at High until crisp (3-5 min.); stir once. Place bacon on a paper towel. Reserve 1 Tbs. drippings.
3. Combine drippings and onion. Cover with plastic wrap; turn back a corner to vent steam. Cook at High until tender (3-4 min.); stir once.
4. Stir in sugar, salt, flour, celery seed, and pepper. Cook at High until mixture boils (30-40 sec.). Stir in vinegar and ½ cup water. Cook at High until liquid boils and thickens slightly (1-2 min.); stir once. Add bacon to dressing. Pour dressing over potatoes. Stir well. *Makes 6 servings.*

Black Bean Soup

1 cup chopped onion
1 clove garlic, minced
2 cans (15 oz. each) black beans, drained
1 can (14-16 oz.) stewed tomatoes, chopped
1 can (13.75-14.5 oz.) chicken broth
1 can (7-8.5 oz.) corn
• 1 can (4 oz.) chopped green chilies
1-2 tsp. ground cumin, or to taste

1. Place onion and garlic in a 3-quart casserole. Cover with lid. Cook at High for 3 to 5 minutes until tender.
 2. Add one can of beans, mash beans with a fork. Add remaining ingredients; mix well.
 3. Cook uncovered, at High for 10 minutes; stir. Reduce power to Medium and cook for 5 minutes. Stir before serving. *Makes about 2 quarts.*
-
-

Appendix

Troubleshooting Guide

Before you call a repair person for your oven, check this list of possible problems and solutions.

Neither the oven's display nor the oven operate.

- Properly insert the plug into a grounded outlet.
- If the outlet is controlled by a wall switch, make sure the wall switch is turned on.
- Remove the plug from the outlet, wait ten seconds, then plug it in again.
- Reset the circuit breaker or replace any blown fuse.
- Plug another appliance into the outlet; if the other appliance doesn't work, have a qualified electrician repair the outlet.
- Plug the oven into a different outlet.

The oven's display works, but the power won't come on.

- Make sure the door is closed securely.
- Check to see if packing material or other material is stuck to the door seal.
- Check for door damage.
- Press Pause/Cancel twice and re-enter all cooking instructions.

The power goes off before the set time has elapsed.

- If there has not been a power outage, remove the plug from the outlet, wait ten seconds, then plug it in again. If there was a power outage, the time indicator will display "88:88" Reset the clock and any cooking instructions.
- Reset the circuit breaker or replace any blown fuse.

The food is cooking too slowly.

- Make sure the oven is on its own 15 amp circuit line. Operating another appliance on the same circuit can cause a voltage drop. If necessary, move the oven to its own circuit.

You see sparks or arcing.

- Remove any metallic utensils, cookware, or metal ties. If using foil, use only narrow strips and allow at least one inch between the foil and interior oven walls.

The turntable makes noises or sticks.

- Clean the turntable, roller ring and oven floor.
- Make sure the turntable and roller ring are positioned correctly.

Using your microwave causes TV or radio interference.

- This is similar to the interference caused by other small appliances, such as hair dryers. Move your microwave further away from other appliances, like your TV or radio.

Care and Cleaning

Follow these instructions to clean and care for your oven.

- Keep the inside of the oven clean. Food particles and spilled liquids can stick to the oven walls, causing the oven to work less efficiently.
- Wipe up spills immediately. Use a damp cloth and mild soap. Do not use harsh detergents or abrasives.
- To help loosen baked on food particles or liquids, heat two cups of water (add the juice of one lemon if you desire to keep the oven fresh) in a four-cup measuring glass at High power for five minutes or until boiling. Let stand in the oven for one or two minutes.
- Remove the glass tray from the oven when cleaning the oven or tray. To prevent the tray from breaking, handle it carefully and do not put it in water immediately after cooking. Wash the tray carefully in warm sudsy water or in the dishwasher.
- Clean the outside surface of the oven with soap and a damp cloth. Dry with a soft cloth. To prevent damage to the operating parts of the oven, don't let water seep into the openings.
- Wash the door window with very mild soap and water. Be sure to use a soft cloth to avoid scratching.
- If steam accumulates inside or outside the oven door, wipe with a soft cloth. Steam can accumulate when operating the oven in high humidity and in no way indicates microwave leakage.
- Never operate the oven without food in it; this can damage the magnetron tube or glass tray. You may wish to leave a cup of water in the oven when it is not in use to prevent damage if the oven is accidentally turned on.

**If you have a problem you cannot solve,
please call our service line:
1-800-SAMSUNG**

Appendix

Specifications

Model Number	MW610WA/MW610WB
Oven Cavity	0.6cuft
Timer	15 minutes
Power Source	120 VAC, 60 Hz
Power Output	600 Watts
Outside Dimensions	18 ^{9/64} "(W) X 9 ^{23/32} "(H) X 12 ^{27/32} "(D)
Oven Cavity Dimensions	11 ^{13/32} "(W) X 7 ^{3/64} "(H) X 12 ^{7/16} "(D)
Net/Gross Weight	22.2/24.4 lbs

Model Number	MW620WA/MW620WB
Oven Cavity	0.6cuft
Controls	5 power levels, including defrost
Timer	35 minutes
Power Source	120 VAC, 60 Hz
Power Output	600 Watts
Outside Dimensions	18 ^{9/64} "(W) X 9 ^{23/32} "(H) X 12 ^{27/32} "(D)
Oven Cavity Dimensions	11 ^{13/32} "(W) X 7 ^{3/64} "(H) X 12 ^{7/16} "(D)
Net/Gross Weight	22.2/24.4 lbs

Model Number	MW630WA/MW630WB
Oven Cavity	0.6cuft
Controls	10 power levels, including defrost
Timer	99 minutes 99 seconds
Power Source	120 VAC, 60 Hz
Power Output	600 Watts
Outside Dimensions	18 ^{9/64} "(W) X 9 ^{23/32} "(H) X 12 ^{27/32} "(D)
Oven Cavity Dimensions	11 ^{13/32} "(W) X 7 ^{3/64} "(H) X 12 ^{7/16} "(D)
Net/Gross Weight	22.2/24.4 lbs

Manual Blok Warranty Card

Warranty Information

Limited Warranty for Original Purchaser

This Samsung product is warranted by Samsung Electronics Canada, Inc. (hereafter referred to as SECA) against manufacturing defects in material or workmanship for the following periods:

Labor: 2 year (carry-in)

Parts: 2 year

Magnetron: 6 years

SECA further warrants that if this product fails to operate properly within the specified warranty period and the failure is due to improper workmanship or defective material, SECA will repair or replace the product at its option.

All warranty repairs or part replacements must be performed by a SECA Authorized Service Center. (To find the nearest SECA Service Center, call 1-800-SAMSUNG.)

Obligation to the Original Owner

The original dated sales receipt must be retained by the customer and is the only acceptable proof of purchase. It must be presented to an SECA Authorized Service Center at the time service is requested before warranty services are rendered. On all carry-in models, transportation to and from the Authorized Service Center is the responsibility of the customer.

Exclusions of the Warranty

This warranty does not cover damage due to accident, fire, flood, and/or other Acts of God: misuse, incorrect line voltage, improper installation, improper or unauthorized repairs, commercial use, or damage that occurs during shipping. Customer adjustments which are explained in this owner's manual are not covered under the terms of this warranty. This warranty will automatically be voided for any unit found with a missing or altered serial number. This warranty is valid only on products purchased and used in the Canada.

SAMSUNG ELECTRONICS

NORTH AMERICAN LIMITED WARRANTY ADDENDUM

Subject to the requirements, conditions, exclusions and limitations of the Original Limited Warranty supplied with Samsung Electronics (SAMSUNG) products, and the requirements, conditions, exclusions and limitations contained herein, SAMSUNG will additionally provide Warranty Repair Service in the United States on SAMSUNG products purchased in Canada, and in Canada on SAMSUNG products purchased in the United States, for the warranty period originally specified, and to the Original Purchaser only.

The above described warranty repairs must be performed by a SAMSUNG Authorized Service Center. Along with this Statement, the Original Limited Warranty Statement and a dated Bill of Sale as Proof of Purchase must be presented to the Service Center. Transportation to and from the Service Center is the responsibility of the purchaser.

Conditions covered are limited only to manufacturing defects in material or workmanship, and only those encountered in normal use of the product.

Excluded, but not limited to, are any original specified provisions for, in-home or on-site services, minimum or maximum repair times, exchanges or replacements, accessories, options, upgrades, or consumables.

For the locations of a SAMSUNG Authorized Service Center in the United States and Canada, please contact SAMSUNG at:

1-800-SAMSUNG (1-800-726-7864)

Or on-line at:

WWW.SAMSUNGUSA.COM and WWW.SAMSONGCANADA.COM

071100

Note

•
•
•

Note

•
•
•

Quick Reference(MW630WA/MW630WB)

Feature	Operation
Set Clock	<ol style="list-style-type: none">1. Press CLOCK.2. Use number buttons to enter time.3. Press CLOCK again.
One Minute+ Cooking	<ol style="list-style-type: none">1. Press the ONE MINUTE + button once for each minute of cooking.2. The time will display and the oven will start.
Defrost	<ol style="list-style-type: none">1. Press DEFROST.2. Press the buttons(0-9) sequentially to enter the desired defrosting time.3. Press START.
Set Cooking Time and Power Levels	<ol style="list-style-type: none">1. Use number buttons to set cooking time.2. Press the POWER LEVEL button. If you want to set the power level to something other than High, press the POWER LEVEL button repeatedly.3. Press START to begin cooking.



Samsung Electronics Co., Ltd.
Feb. 2001
Printed in Malaysia

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>