

Storey Controller

HCE 60

Installation and Operation



Contents

Overview	3
Application	3
Installation procedure	4
Classifying zones and actuators	4
Installation	4
Configuration and electrical connection	4
Start-up	4
Creating a zoning plan	5
Determining temperature zones	5
Filling out zoning plan	6
Installation	10
Wall installation	11
DIN rail installation	12
Installing Hometronic components	12
Configuration and electrical connection	13
Opening housing	14
Cabling connections	16
Start-up	26
Preparing for start-up	26
LED indicators on storey controller	28
Operating modes of storey controller	29
Buttons	30
Cooling function	30

Assigning zones and issuing room names	32
Example: Assigning an HCW 22 setpoint adjuster to zone 1	32
Example: Assigning room name LIVING to zone 1	34
Assigning wireless setpoint adjuster HCU 30 to a temperature zone	36
Assigning setpoint adjusters of type HCW 23 to a zone	37
Assigning room names for cooling function	37
Canceling assignment	38
Deleting assignment of a room name at the Hometronic Manager	39
Saving settings on Hometronic Manager	40
Checking configuration	40
Checking wireless transmission	41
Checking assignment of room names	42
Displaying faults	42
Completing start-up	43
Resetting storey controller to state of delivery	44
Appendix	45
Glossary	45
Help with problems	46
Overview of Hometronic heating components	49
Zoning plan	50
Notes	52

Overview

For your information

Technical terms are explained in the glossary (Page 45). They are identified in the text by an *.

Application

The storey controller HCE 60 receives information on the temperature of the room from the setpoint adjusters* and the Hometronic Manager. Using this information, the storey controller regulates the boiler feedback*, the pump relay*, and the thermal actuators* (see Page 48, Hometronic heating components).

It has a self-learning controller (fuzzy logic) which automatically adjusts itself to the ambient conditions. The desired room temperature is reached quickly and then maintained.

A sticker has been included on the back for a quick overview of the display and operation. It can be attached to the housing of the storey controller.

Installation procedure

Classifying zones and actuators

- Determine which heating circuits* are controlled by the storey controller.

Installation

- Install Hometronic components.

Configuration and electrical connection

- Set the storey controller to the actuator type, attach cables to the respective connections and connect components together.

Start-up

- Assign setpoint adjusters and any room temperature sensors to the temperature zones.
- Assign room names at the Hometronic Manager if necessary.
- Assign the time program of the wireless setpoint adjuster HCU 30 to the temperature zones if necessary.

Creating a zoning plan

A temperature zone is an area of the building, e.g. a room, in which the setpoint temperature* is set with a setpoint adjuster. The storey controller controls all thermal actuators of a temperature zone identically.

5 temperature zones can be set up for each storey controller. The expansion module HCS 60 increases the number of temperature zones for each storey controller to 8. A maximum of 3 actuators can be connected in each zone.

Thus the total number of actuators which can be controlled by one storey controller is limited to 24.

Determining temperature zones



Caution

Damage caused by equipment from other manufacturers!

The storey controller was designed for use with components from Honeywell only!

- ▶ Use only H 200 BG (closed without current) or H 200 BO (open without current)-type actuators.
- ▶ Group actuators (by type and location) which are managed by the storey controller.
- ▶ Group together all actuators which are controlled by a setpoint adjuster in a temperature zone.

Creating a zoning plan

For more than 8 temperature zones or 24 actuators:

- ▶ Determine the number of additional storey controllers required using the following table:

Temperature zones (maximum)	Actuators (maximum)	No. of storey controllers
8	24	1
16	48	2
24	72	3




The example at the end of this section shows zone divisions with corresponding zoning plan.

Filling out zoning plan

- ▶ Copy the sample zoning plan (see Appendix, Page 50) (archive it).
- ▶ Enter the type and installation location of the respective actuator in each temperature zone.
- ▶ Assign a setpoint adjuster to each temperature zone.
- ▶ Assign room names if necessary.
- ▶ Hand over the zoning plan to the customer after installation.

Example of zone divisions



1, 2 etc. = Zone

A = Living room

B = Dining room

C = Kitchen

D = Hall

E = Bedroom

F = WC

G = Bathroom

Creating a zoning plan

This example shows:

- The living area is covered by 6 temperature zones. **The additional module HCS 60 is required for this partitioning.**
 - A total of 8 actuators are controlled by the storey controller.
- Up to 8 temperature zones can be controlled by the additional module HCS 60. Planned temperature zones are generated in gray.
- **i** The room names for each temperature zone are entered at the Hometronic Manager.

The division yields the following zoning plan:

Temperature zone	Actuator (type, location)	Setpoint ad-juster (location)	Room name at HCM 200
Zone 1	Heating loop 1 (living room)	Living room	"Living"
	Heating loop 2 (living room)		*
	Heating loop 3 (living room)		
Zone 2	Heating loop 1 (dining room)	Dining room	"Dining" *
Zone 3	Heating loop 1 (kitchen)	Kitchen	"Kitchen" *
Zone 4	Heating loop 1 (bedroom)	Bedroom	"Bedroom" *
Zone 5	Heating loop 1 (WC)	WC	"WC" *
Zone 6	Heating loop 1 (bathroom)	Bathroom	"Bathroom" *

* Cooling optional

Installation



Caution

The storey controller has a wireless receiver whose function is impaired by metal objects or wireless devices.

- ▶ When selecting the operating site ensure that there is sufficient distance to metallic objects and radio devices.
- ▶ Select another installation site if the wireless interference cannot be rectified.

The storey controller was designed for installation in a distributor box. If insufficient space is available, select an area where the storey controller can communicate with the setpoint adjusters wirelessly without interference and which is protected from moisture and water.


The storey controller can be installed in one of two ways:

- Wall installation
- DIN rail installation

Wall installation

Four 4.2 mm holes for installation are located on the storey controller.

Dimensions of storey controller in mm




i Note the 60 mm installation height of the storey controller! If the storey controller is installed at a severe angle, the transformer must be on top to allow for ventilation.

- ▶ Mark, drill and insert plugs into fastening holes.
- ▶ Screw on the storey controller.

DIN rail installation

- ▶ Place housing on the DIN rail from below (1).
- ▶ Press housing upward and snap into place (2).



Installing Hometronic components

- ▶ Install components as described in the accompanying installation instructions.

Configuration and electrical connection



Danger

Danger to life through electric shock!

Live electrical contacts (actuator outputs, mains fuse and transformer) lie open while the device is being cabled. Touching a live contact causes critical injuries.

- ▶ Work may only be carried out by authorized specialized personnel.
- ▶ Unplug the power plug before opening the housing.



Caution


Damage to exposed components!

The electronic components of the storey controller and plug-in module can be damaged by static electricity discharge!

- ▶ Do not touch such components.
- ▶ Touch an grounded piece of metal to discharge static electricity from your body.

Opening housing


- ▶ Loosen the screw on the front (1).
- ▶ Push both snap locks inward (2).
- ▶ Remove the housing cover from above (3).



Plugging in the expansion module (optional)

The expansion module HCS 60 expands the number of possible temperature zones per storey controller from 5 to 8.


- ▶ Insert expansion module into the intended slot.



Setting actuator

i Only one type of actuator can be connected to a storey controller at a time. If actuators which are open with current and actuators which are closed with current are to be used, 2 storey controllers with the respective suitable controller are required.



1. Configuration switch
(O = Open, C = Closed)
2. Setpoint temperature of ceramic fuse (type:
230 V AC; 2.5 A, fast-
blowing; 5×20 mm)



i The actuators are protected by the ceramic fuse.

- ▶ Check the type of actuator being used.
- ▶ Set the switch according to the following table.

Configuration and electrical connection

Switch position	Actuator type	Property
	Normally closed	Opens the heating circuit if power is present at its control input.
	Normally open	Opens the heating circuit if power is not present at its control input.

Cabling connections


Permissible cable types and lengths

Cable (designation)	Connection between storey contr. HCE 60 and ...	Max. permissible length
JE-LiYCY 2x2x0.8	Setpoint adjuster HCW 23*	100 m
CY 2x2x0.14	Setpoint adjuster HCW 23*	100 m
JE-Y(St)Y 2x2x0.8	Setpoint adjuster HCW 23*	100 m
	MCR pre-regulator	100 m
	Pump relay HREL1	100 m
1.5 mm ²	Thermal actuators H200 BO and H200 BG	100 m
Prefabricated cable	Thermal actuators H200 BO and H200 BG	1 m (3 m)
Prefabricated cable	Antenna HRA1	1.2 m

* or heating/cooling switchover contact

i Use only cables with wire diameters up to 1.5 mm^2 . We recommend the cable type JE-Y(St)Y $2 \times 2 \times 0.8$. Use the accompanying connector types and cables of sufficient length.

1. Connector (1 to 12)
2. Connections for expansion module HCS 60
3. Antenna connector
4. Connector of actuator for zones 1 through 8



In general, each zone can control up to 3 actuators. 3 actuators can be connected for zone 1 and one each for zones 2 through 5. One connection for the expansion module is available for each of the zones 6 through 8.

i The prefabricated cable of the thermal actuators can be extended from 1 to 3 meters. This cable is available plug-in-ready as type HCV 2.

Connecting actuators



Danger

Danger to life through electric shock!

Live electrical contacts (actuator outputs, mains fuse and transformer) lie open while the device is being cabled. Touching a live contact causes critical injuries.

- ▶ All work may only be carried out by authorized specialized personnel.

If more than 4 actuators are to be connected to the storey controller, the cables of the actuator must be wired in a distribution box.


The storey controller can control up to 24 actuators. However, no more than 3 actuators may be connected in any one zone.




The prefabricated cable of the actuators can be extended from 1 to 3 meters. This cable is available plug-in-ready as type HCV 2.

- ▶ Lay actuator cables to distribution box.
- ▶ Wire actuator lines.
- ▶ Extend cables to storey controller with the HCV 2 cable.


- ▶ Insert connector of actuator connection cables into the sockets of the respective zones.



- ▶ Squeeze the cables into the stress relief clamp.



- ▶ Break out the openings for the cables on the housing using a diagonal cutter.




Connecting setpoint adjuster HCW 23

The setpoint adjuster HCW 23 is given fixed assignment via the zone wiring. Alternatively, a switchover relay can be connected.

i If the remote controller HCW 23 is removed, the assignment has to be removed as well. Refer to "Canceling assignment" on Page 38.

- ▶ Use cables in accordance with the table on Page 16.
- ▶ Attach the connectors of the setpoint adjusters to the connector of the storey controller as shown in the following diagram.

1. Setpoint adjuster 1 or heating/cooling switchover contact
 2. Setpoint adjuster 2
 3. Zone 1
 4. Zone 2
 5. Bus (not activated)
 6. Boiler feedback
 7. Pump relay HREL 1
- TW Temperature selector input
RF Room sensor input
⊥ Ground




Connecting boiler regression and pump relay

Boiler feedback is possible with controllers MCR 200, MCR 40 and ZG 252 N.


- ▶ Connect the inputs in accordance with the accompanying instructions. (Ground input on terminal 10 and temperature input on terminal 5 of the HCE 60.)

With controller MCR 40, the temperature and ground inputs are located at the following terminals:



Configuration and electrical connection

With controller ZG 252 N, the temperature and ground inputs are located at the following terminals:




i Depending on the design, the temperature selector and ground inputs are found on different terminals of the controller MCR 200.

Boiler feedback

If control cables for heating (“boiler regression”) and for the pump relay are available:


- ▶ Use cables in accordance with the table on Page 16.
- ▶ Connect boiler regression and pump relay to storey controller as shown in the following diagram.

Connections of storey controller and pump relay



Inserting connectors


- ▶ Insert connectors into the connector strip of the storey controller.
- ▶ Insert connector of antenna cable into the antenna socket of the storey controller.



Installing antenna

i An antenna must be connected to each storey controller! Take the antenna function into account when selecting the operating site:

- ▶ Antenna (1) must be installed outside metal housings (e.g. switch cabinets (4)).
- ▶ Do not lengthen antenna cable.
- ▶ Install antenna at a suitable location near the storey controller (3). Wireless connection to setpoint adjuster (2) must be ensured.



- ▶ Insert antenna cable into the antenna socket of the storey controller.

Closing housing of storey controller

- ▶ Place cover on housing.
- ▶ Snap left and right snap locks into place.
- ▶ Tighten screw on the front.


Start-up

During start-up, setpoint adjusters – and the time program of the wireless setpoint adjuster HCU 30 if applicable – are assigned to the temperature zones of the storey controller. A room name is defined for each temperature zone at the Hometronic Manager.


Preparing for start-up

Starting up setpoint adjuster HCW 22

- ▶ Set adjustment dial to position 0.
- ▶ Open housing: Press snap lock (1) and remove housing cover (2).



- ▶ Insert 2 mignon batteries of type LR06, 1.5 V.
 - ▶ Ensure that the polarity is correct.
1. Send button (required for start-up)



Starting up storey controller

- ▶ Plug in power plug.

The mains voltage LED  illuminates.

Starting up setpoint adjuster HCU 30

- ▶ See instructions of setpoint adjuster HCU 30.




Starting up room temperature sensor HCF 22


- ▶ See instructions of room temperature sensor HCF 22.

LED indicators on storey controller

The LEDs on the storey controller indicate the operating mode of the storey controller and the installed temperature zones.

Meaning of the 3 left-hand LEDs:

	Illuminating (green)	Normal mode
	Illuminating (red)	Group fault
	Flashing	Fault display
	Illuminating (yellow)	Installation mode
	Flashing	Device display



LEDs 1 through 8 are assigned to the temperature zones and can illuminate green, yellow and red. The meaning of the color depends on the selected operating mode.

Operating modes of storey controller

Normal mode

In normal mode, LEDs 1 through 8 provide information on the position of the actuators:

Green	Thermal actuator opened
Off	Thermal actuator closed

Fault mode

In fault mode, the status displays provide information on a fault in the individual temperature zones.

Refer to section "Displaying faults" on Page 42.

Installation mode

In installation mode, temperature zones are assigned to the setpoint adjusters and the Hometronic Manager.

Refer to section "Assigning zones and issuing room names" on Page 32.



Device display


The device display informs you of the configuration of your Hometronic system: i.e. the assignment of setpoint adjusters to a temperature zone of room names at the Hometronic Manager.

Refer to section "Checking configuration" on Page 40.

Buttons

The storey controller has 2 buttons:


- Fault button :
Pressing the Fault button switches the storey controller to the fault display. Refer to section "Displaying faults" on Page 42.
- Installation button :
Pressing the Installation button switches the storey controller to installation mode or to the device display.






Cooling function

If the HCE 60 is used as a cooling regulator, this function must be activated during installation.

Activating cooling function


- ▶ Press Fault button  for 4 seconds.

The storey controller switches to the fault display. The  LED flashes red while pressing and then illuminates. The device display shows whether heating or heating/cooling is activated:

 LED flashing	Heating/cooling active
 LED illuminating constantly	Heating active

Change setting if necessary:

- ▶ Press the Installation button .

The yellow  LED switches between flashing and constant illumination.

In the heating/cooling operating mode, LEDs 1 through 8 of the temperature zones indicate whether the temperature zones are heated or cooled:


Red	Heating
Green	Cooling

i The display is cleared automatically after 30 seconds and the device returns to normal mode. There is no other option for exiting the fault display.

Assigning zones and issuing room names


The following section describes how a setpoint adjuster is assigned to a temperature zone and how a room name is then assigned to this zone. The procedure is identical for both device types.


- **i** A temperature zone can only be assigned one setpoint adjuster. If a room temperature sensor HCF 22 is combined with a remote setpoint adjuster HCW 22, i.e. assigned to the same zone, first assign the remote setpoint adjuster and then the room temperature sensor.

If the installation button  at the storey controller is not pressed for longer than 4 minutes, the storey controller returns automatically to normal mode.


Example: Assigning an HCW 22 setpoint adjuster to zone 1


In the following example the setpoint adjuster HCW 22 is assigned to zone 1. Subsequently the room name "Living" is assigned to zone 1 in the time program of the Hometronic Manager.

- ▶ Find the zoning plan.
- ▶ Press and hold Installation button  on storey controller for at least 2 seconds.

The  LED illuminates. The LED of zone 1 flashes red.

The storey controller is in installation mode and waits for the signal from the setpoint adjuster.



- i** To assign the setpoint adjuster to another zone, press the Installation button  until the LED of the desired zone flashes red.
- ▶ Press the Send button of the setpoint adjuster.
*The setpoint adjuster is assigned to zone 1.
The LED of the selected zone lights continuously red.*
- i** If no Hometronic Manager is installed, the storey controller operates with a basic value of 20 °C. For information on how the configuration is checked please refer to Page 40 .

Example: Assigning room name LIVING to zone 1

- ▶ Press the installation button  at the storey controller once more.
The LED of the selected zone flashes green. The storey controller waits for a signal from the Hometronic Manager.

The Hometronic Manager is in automatic mode.

The display on the Hometronic Manager shows the standard display, for example:

```
HOMETRONIC
WE 29.10.1999  11:15
No Lifestyle active
LIVING                20.0 C
```

- ▶ Press the Input button.
The following text is displayed:

```
MENU
SET DATE/TIME
ACTIVATE LIFESTYLE
LIVING                20.0 C
```

- ▶ Turn the Input button to the right until "Menu" is selected.

```
MENU
SET DATE/TIME
ACTIVATE LIFESTYLE
LIVING                20.0 C
```

Assigning zones and issuing room names

- ▶ Press the Input button.

The following text is displayed:

```
LIFESTYLES  
TIME PROGRAMS  
SETTINGS  
VERSION
```

- ▶ Select the "Settings" submenu and press the Input button.

The following text is displayed:

```
INSTALLATION  
DE-INSTALLATION  
FUNCTION EXTENSION  
SENSOR FUNCTION
```

- ▶ Select the "Installation" submenu and press the Input button.

The following text is displayed:

```
HEATING/COOLING  
SHUTTERS  
DEVICES/LIGHT  
SENSOR
```

- ▶ Select the "Heating" submenu and press the Input button.

A list of the room names (possible temperature zones) appears in the display:

```
LIVING  
DINING  
KITCHEN  
BEDROOM
```



- ▶ Turn the Input button until "Living" is selected.

- ▶ Press the Input button.

*An * appears after "Living".*

```
LIVING *  
DINING  
KITCHEN  
BEDROOM
```

The LED on the storey controller in zone 1 illuminates green. The name "Living" has been assigned to temperature zone 1.

- ▶ Enter room name in zoning plan.
- ▶ Repeat these steps until a room name is assigned to all temperature zones.
- ▶ Press the installation button  until the LED  extinguishes.

The storey controller is back in normal mode.

i If the installation button is not pressed for longer than 4 minutes, the storey controller changes to normal mode. The assigned temperature zones remain stored in the storey controller, even after a power failure.

Assigning wireless setpoint adjuster HCU 30 to a temperature zone

For information on assigning the wireless setpoint adjuster HCU 30 to a temperature zone, refer to the operating instructions of the wireless setpoint adjuster.

Assigning setpoint adjusters of type HCW 23 to a zone

Setpoint adjusters of type HCW 23 have a fixed allocation to zones 1 and 2 due to their wiring.


i If the remote controller HCW 23 is removed, the assignment has to be removed as well. "Refer to "Canceling assignment" on Page 38.

Assigning room names for cooling function



If the cooling function is activated (see Page 30), 2 room names can be assigned for each temperature zone. Example: "Heating living", "Cooling living". The time programs and setpoint values are activated by the heating or cooling input signal.

Switch closed (terminals 1 and 3)	Cooling active
Switch open (terminals 1 and 3)	Heating active

Assigning 2 room names to a temperature zone





- ▶ Enter room name in zoning plan.
- ▶ Press Installation button .
The LED of zone 1 flashes red.
- ▶ Assign next setpoint adjuster.
- ▶ Continue when you have assigned the next setpoint adjuster:

Assigning zones and issuing room names



- ▶ Press Installation button .
The LED of zone 1 flashes green.
- ▶ Assign room names for **heating**.
- ▶ Press Installation button .
The LED of zone 1 flashes green/orange.
- ▶ Assign room names for **cooling**.
- ▶ Repeat these steps until 2 room names are assigned to all temperature zones.

Canceling assignment

Canceling assignment of setpoint adjuster to a temperature zone

- ▶ Press and hold Installation button  at least 2 seconds.
The  LED illuminates. The LED of zone 1 flashes red.
- ▶ Press Installation button  repeatedly until the LED of the zone to be removed flashes red.
- ▶ Press Fault button  until the LED of the temperature zone goes out.
The assignment of the setpoint adjuster to the temperature zone has been canceled.

Canceling assignment of the room name or time program to the temperature zone


- ▶ Press the Installation button  again, until the LED of the zone to which the time program or room name is assigned, flashes green.
- ▶ Press Fault button  until the LED of the temperature zone goes out.

The assignment of the room name or the time program to the temperature zone is canceled.

Deleting assignment of a room name at the Hometronic Manager

- ▶ Change to submenu "Settings" as described on Page 34.


The following text is displayed:



```
INSTALLATION
DE-INSTALLATION
FUNCTION EXTENSION
SENSOR FUNCTION
```

- ▶ Select the "De-Installation" submenu and press the Input button.

The following text is displayed:




```
HEATING/COOLING
SHUTTERS
DEVICES/LIGHT
SENSOR
```

Assigning zones and issuing room names


- ▶ Select the "Heating" submenu and press the Input button.

A list of the assigned room names (temperature zones) appears in the display:



- ▶ Select room name (in this case, Living) and press the Input button.

*The * symbol after the room name disappears:*




The assignment is deleted and can be reassigned.

Saving settings on Hometronic Manager

Before start-up is completed, the settings at the Hometronic Manager must be saved.

For information on saving settings, refer to the operating instructions of the Hometronic Manager in the chapter entitled "Adaptation".

Checking configuration

- ▶ Press Installation button  briefly.


The  LED flashes yellow.

The storey controller is in the device display.

The colors of LEDs 1 through 8 indicate the configuration of the temperature zones.

Off	No device installed
Red	Setpoint adjuster is installed
Green	Hometronic Manager resp. wireless setpoint adjuster HCU 30 are installed
Orange	Hometronic Manager and setpoint adjuster are installed

i If heating/cooling is activated, the following information can be called up:

- ▶ Press Installation button  briefly again.

The colors of LEDs 1 through 8 indicate the assignment of room names to the temperature zones.

Green	Room name for cooling assigned
Red	Room name for heating assigned
Orange	Room name for heating/cooling assigned

Checking wireless transmission


- ▶ Press Send button on setpoint adjuster.
*LEDs 1 through 8 of the assigned zone flash up to three times.
 The wireless transmission stops.*

Checking assignment of room names


- ▶ Change setpoint temperature at Hometronic Manager (see instructions of Hometronic Manager)
*LEDs 1 through 8 of the assigned zone flash up to three times.
The assignment is correct.*

The storey controller exits the device display after approx. 60 seconds and returns to normal mode.

Displaying faults

If the  LED illuminates, a fault is present in at least one temperature zone.

- ▶ Press Fault button .

The  LED flashes red. The storey controller switches to the fault display.

The colors of LEDs 1 through 8 now provide information on a fault in the temperature zones:

Off	No fault
Red	Cable break / no connection to setpoint adjuster
Green	No connection to Hometronic Manager resp. wireless setpoint adjuster HCU 30
Orange	No connection to setpoint adjuster and Hometronic Manager

The storey controller exits the fault display after approx. 60 seconds and returns to normal mode.

Completing start-up

Closing setpoint adjuster



- ▶ Replace cover and snap in both snap locks.

Handing over zoning plan


- ▶ Hand over the completed zoning plan and the installation instructions to the customer. Both documents are important, as changes to the system may be made in future.

Resetting storey controller to state of delivery

i All current assignments are lost if the storey controller is reset to the state of delivery. The storey controller retains its configuration after a power failure.

- ▶ Pull out the connector of the storey controller.
- ▶ Keep the buttons  and  at the storey controller pressed at the same time and plug in the connector again.

The  and  LEDs illuminate. The LED of zone 1 is red.

- ▶ Press the installation button  briefly.
The LED of Zone 1 is extinguished. The LED of zone 2 is illuminated.

- ▶ Press the fault button .

- ▶ Pull the connector of the storey controller again and plug it in again.
The storey controller is reset to the state of delivery.

Note to installer

After the storey controller has been started up, you should inform your customer about the Hometronic system:

- ▶ Familiarize your customer with the operation of the Hometronic.
- ▶ Explain the manual operation of the components.
- ▶ Point out particular features and extension possibilities of the respective customer installation.

Appendix

Glossary

Boiler feedback

Hometronic controls the heating boiler via an analog control device of Honeywell.

Heating circuit

Area controlled by an actuator.

Hometronic

Home automation system from Honeywell.

Hometronic Manager

Central operating device of the Hometronic System.

Room temperature sensor

Detects the room temperature and transfers it to the storey controller.

Setpoint adjuster

Senses the actual temperature and changes the setpoint temperature. Installed in a user-friendly location in each zone.

Setpoint temperature

Room temperature which is to be reached.

Thermal actuator

Opens and closes a heating circuit. Controlled by the storey controller.


Time program


Defined combination of setpoints and switching points at the Hometronic Manager.



Zoning plan

Overview of the temperature zones of the storey controller.

Help with problems

Problem	Cause/Solution
LED  does not illuminate when power plug is plugged in.	Mains voltage not connected. ▶ Check voltage of electrical outlet. ▶ Check fuse at storey controller.
LEDs 1 through 8 of the zones do not illuminate red continuously during start-up.	The setpoint adjuster cannot be assigned. ▶ Check whether batteries in setpoint adjuster are inserted properly. ▶ Check wireless connection.
LEDs 1 through 8 of the zones do not illuminate green continuously during start-up.	The room name cannot be assigned. ▶ Check whether Hometric Manager is installed. ▶ Check whether or not a room name is assigned to zone. ▶ Reassign zone if applicable.
Not all rooms are warmed/cooled.	▶ Check heating and inlet temperature. ▶ Check adaptation to thermal actuator (see Page 15). ▶ Check fuse of storey controller. If fuse is defective: ▶ Check actuators for short circuit.

Problem	Cause/Solution
A room name cannot be installed at the Hometronic Manager.	<p>An "*" is already present next to the room in the "Installation" menu. The room name was already issued.</p> <ul style="list-style-type: none">▶ Uninstall room name.▶ For assigning again (see "Assigning zones and issuing room names" on Page 32).
The  LED illuminates after start-up.	<p>A fault is present in one of the temperature zones. See Page 42.</p> <ul style="list-style-type: none">▶ Check wireless connection.▶ Check cabling for cable break.▶ Check whether zone is assigned correctly.▶ Check batteries of the storey controller and wireless setpoint adjuster.
Room controlled incorrectly.	<ul style="list-style-type: none">▶ Check whether adjusting ring of setpoint adjuster is at position 0.▶ Check whether adjusting ring can be turned between -12 and +12 with housing cover removed.▶ Check whether or not a setpoint adjuster is assigned to room.



Overview of Hometronic heating components

A	Setpoint adjuster HCW 22 Regulates setpoint temperature for each temperature zone via adjustment dial
B	Wireless setpoint adjuster HCU 30 Regulates setpoint temperature for each temperature zone via adjustment dial; defines time programs for comfort and economy temperatures
C	Room temperature sensor for storey controller HCF 22 Transmits room temperature information to storey controller
D	Hometronic Manager Central operating unit of the house-automation system
E	Setpoint adjuster HCW 23 (wired) Regulates setpoint temperature for each temperature zone via adjustment dial
F	Storey controller HCE 60 Controls actuators of floor heaters/radiators; communicates with setpoint adjusters and room temperature sensors
G	Antenna
H	Boiler feedback HS 30
I	Pump relay
J	Thermal actuators

Zoning plan

Zone	Actuator (type, location)	Setpoint adjuster (location)	Room name
1			Heating
			*Cooling
2			Heating
			*Cooling
3			Heating
			*Cooling
4			Heating
			*Cooling
5			Heating
			*Cooling

* Cooling optional

Distribution limitation

- max. 5 (8) zones per storey controller
- max. 3 connections per zone
- max. 24 actuators per storey controller
- only one type of thermal actuator per storey controller (normally open or normally closed)
- either heating loops or radiators for each storey controller (floor heating)
- max. 8 zones for heating/cooling, as a room for heating and a room for cooling must be assigned for each zone

Notes

Notes

Honeywell AG

Böblinger Straße 17
D – 71101 Schönaich
Tel. 01801 / 466390

The right is reserved to make
modifications

This company is certificated to

DIN EN ISO
9001/14001

This document is definitive for the enclosed product and replaces all previous publications.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>