

HP ProLiant Lights-Out 100 Remote Management User Guide

for HP ProLiant DL140 G2, DL145 G2, ML110 G3, and ML150 G2 Servers



Part Number 436853-001
January 2007 (First Edition)

© Copyright 2007 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Confidential computer software. Valid license from HP required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation. Windows Server 2003 is a U.S. trademark of Microsoft Corporation. Java is a U.S. trademark of Sun Microsystems, Inc.

Audience assumptions

This document is for the person who installs, administers, and troubleshoots servers and storage systems. HP assumes you are qualified in the servicing of computer equipment and trained in recognizing hazards in products with hazardous energy levels.

Contents

Operational overview	5
User guide overview	5
Server management.....	5
Server management features.....	5
Installation	7
Remote management card kit contents.....	7
Pre-installation procedures	7
Installing the remote management card on ProLiant ML110 G3 servers	8
Installing the remote management card on ProLiant ML150 G2 servers	9
Post-installation procedures.....	9
Configuration	11
Configuring network access.....	11
Establishing user accounts	11
Using the serial port	12
Enabling serial access to the LO100	12
LO100 serial port configuration	13
Using TCP/IP over Ethernet management port	13
Selecting an Ethernet management port.....	14
Obtaining a DHCP IP address from the BIOS Setup Utility.....	14
Setting up a static IP address from the BIOS Setup Utility	15
Enabling telnet and HTTP services.....	15
Updating the firmware	16
Updating the firmware remotely	16
TFTP settings	17
Using LO100	19
SSL overview	19
SSH overview	20
Importing a certificate	21
Creating a certificate	21
Installing a certificate or private key through the CLP	21
CLP overview	22
Using CLP.....	22
Base commands	23
Specific commands.....	27
IPMI 2.0 support	27
Logging in to LO100	28
Logging in through a web browser	28
Logging in through the CLP	29
Browser main menu options.....	29
Hardware Inventory page	30
Controlling server power remotely	30
Controlling server power from a browser.....	31
Controlling server power through the CLP	31
Controlling server power through the BIOS Setup Utility.....	32

Monitoring sensors	32
Viewing sensors data from a web browser	32
Viewing sensors data from the BIOS Setup Utility	32
Platform event filtering configuration	33
Using the system event log	34
Accessing the system event log from a web browser	34
Accessing the system event log from the CLP	35
Accessing the system event log from the BIOS Setup Utility	35
Network settings	36
Configuring network settings using a web browser	36
Configuring network settings using the CLP	36
Configuring network settings using the BIOS Setup Utility	37
Using the virtual floppy feature	38
Configuring the TFTP Server	39
Configuring virtual floppy from a Web browser	39
Configuring the virtual floppy from the BIOS setup	40
Configuring virtual floppy from the CLP	40
Rebooting the server	41
Platform event trap configuration	41
User administration	42
Changing user settings through a web browser	42
Changing user settings through the CLP	43
Accessing the remote console through telnet	43
BIOS console text redirection through telnet	43
Linux console redirection	44
Microsoft Windows® EMS management	45
HP SIM support	46
Acronyms and abbreviations	47
Index	50

Operational overview

In this section

User guide overview	5
Server management.....	5
Server management features.....	5

User guide overview

This guide covers the standard and optional operational features of the LO100 used in HP ProLiant DL140 G2, DL145 G2, ML150 G2, and ML110 G3 servers.

This guide is an update to the HP ProLiant DL140 G2, DL145 G2, ML150 G2, and ML110 G3 LO100 remote management user guides.

Server management

HP ProLiant Lights-Out 100 delivers basic remote control of vital server resources, supports IPMI 2.0, and provides system administrators with access to the server at any time, even before an operating system is installed on the server.

HP ProLiant Lights-Out 100 provides text mode console redirection, DMTF SMASH compliant command line interface, and browser access to many of the same system management functions. You can access LO100 through a dedicated Ethernet port or through the server serial port.

Server management features

Using the Lights-Out 100 Remote Management processor, you can:

- Switch between console redirection and the command line using either the dedicated management or serial port
- Communicate securely using SSL and SSH
- Remotely power up and power down the server
- Perform warm or cold server reboots
- Reboot the server to a virtual floppy
- Remotely monitor server-state voltage, fan speed, and system state (S0 or S5)
- Access the System Event log
- Configure TCP/IP settings for the NIC
- Change user passwords
- Access the BMC and server controls using a standard browser or new industry standard SMASH CLP command-line interface

- Access command-line help
- Manage the server with IPMI 2.0-compliant applications

Installation

In this section

Remote management card kit contents	7
Pre-installation procedures	7
Installing the remote management card on ProLiant ML110 G3 servers.....	8
Installing the remote management card on ProLiant ML150 G2 servers.....	9
Post-installation procedures.....	9

Remote management card kit contents

The remote management card kit is required only on ProLiant ML110 G3 and ProLiant ML150 G2 servers.

ProLiant ML110 G3

- HP ProLiant ML110 G3 Remote Management Card
- Spacer support
- *HP Lights-Out 100 Remote Management Card Installation Instructions for HP ProLiant ML110 Generation 3 Servers*

ProLiant ML150 G2

- HP ProLiant ML150 G2 Remote Management Card
- Hexnut screw
- *HP Lights-Out 100 Remote Management Card Installation Instructions for HP ProLiant ML150 Generation 2 Servers*

Pre-installation procedures

The installation procedures in this document are intended for individuals who are qualified in the servicing of computer equipment and trained in recognizing hazards in products with hazardous energy levels.



WARNING: Failure to properly turn off the server before you open the server may cause serious damage to the equipment as well as bodily harm.



CAUTION: Follow the ESD precautions listed in your server guide when handling the remote management card.



IMPORTANT: Observe the pre- and post-configuration procedures described in later sections when installing the remote management card.


NOTE: The procedures described in this section assume that the server is positioned on a flat, stable surface.

1. Back up the server data.


2. Shut down the operating system as outlined in the operation system instructions.
3. Power off the server and all the peripherals connected to it.
4. Unplug all cables from the power outlets to avoid exposure to high energy levels that can cause burns when parts are short-circuited by metal objects such as tools or jewelry.
5. Label each cable, if not already labeled, to expedite reassembly.
6. Disconnect telecommunication cables to avoid exposure to shock hazard from ringing voltages.
7. Open the server according to the instructions described in your server manual.

Installing the remote management card on ProLiant ML110 G3 servers

1. Remove the access panel.
2. Lay the server on its unexposed side to access the system board.
3. Locate the remote management card connectors on the system board.




4. Install the remote management card in the connectors on the system board.



5. Reinstall the system covers following the "Post-installation procedures (on page 9)".

Installing the remote management card on ProLiant ML150 G2 servers

1. Remove the access panel.
2. Lay the server on its unexposed side to access the system board.
3. Locate the remote management card connectors on the system board.
4. Install the remote management card in the connectors on the system board.



5. Reinstall the system covers following the "Post-installation procedures (on page 9)".
6. Verify BIOS version and switch settings for the card.

To ensure proper operation of the ProLiant ML150 G2 Lights-Out 100 remote management processor, the server BIOS must be version 0.28 or later. You can download the latest BIOS for your server on the HP website (<http://www.hp.com/support>).

The remote management card switches must be set to factory default settings.

Switch	Setting
SW1	Off
SW2	On
SW3	On
SW4	Off

Post-installation procedures

1. Be sure all components are installed according to the "Pre-installation procedures (on page 7)."
2. Be sure you have not left any loose tools or parts inside the server.
3. Reinstall any expansion boards, peripherals, board covers, and system cables previously removed.
4. Reinstall the system covers.
5. Connect all external cables and the AC power cord to the system.

6. Press the power button on the front panel to turn on the server.

Configuration

In this section

Configuring network access.....	11
Establishing user accounts.....	11
Using the serial port.....	12
Using TCP/IP over Ethernet management port.....	13
Updating the firmware.....	16

Configuring network access

The server is connected to the network by a standard Ethernet cable. Using this connection, you can access the remote management CLP, verify POST remotely, and access the BIOS Setup Utility remotely.

To configure network access:

1. Connect a standard Ethernet cable from the LO100 to a network jack.
2. Obtain the DHCP IP address by using one of the following methods:
 - o Look at the DHCP clients table.
 - o Press the **F10** key during POST, and read the IP address from the BIOS Setup Utility under Advanced/IPMI/LAN Setting. See "Obtaining a DHCP IP address from the BIOS Setup Utility (on page 14)" for more information.
3. Using the DHCP IP address, use telnet to log into the remote management CLP, or use a web browser to access the HTML interface.

To set up a static IP address, see "Setting up a static IP address from the BIOS Setup Utility (on page 15)" for more information.

Establishing user accounts

LO100 supports three types of user accounts, with varying levels of permissions to view and control features. For more information about user accounts, see the "User administration (on page 42)" section. Two accounts are available by default, one of type administrator and one of type operator. While one user account always has the administrator privilege, the other user account is customizable.


The administrator account enables the user to execute the full set of CLP commands and change management processor configuration. The default name for the administrator account is admin, and the default password is admin.

The operator account enables the user to execute common commands and functions, but restricts access to specific functions, such as adding and changing user account information and changing the configuration of the management processor. Log in with the operator account to perform common functions. The default name for the operator account is Operator, and the default password is Operator.

For more information about how to log in to LO100, see the "Logging in to LO100 (on page 28)" section.

Using the serial port

The server serial port provides basic serial port functionality and serves as an interface to LO100. You can configure the system serial port for exclusive use with LO100.

 **CAUTION:** After enabling the serial port for use with LO100, legacy serial devices might not function correctly if attached to the serial port.

You must configure the LO100 serial port hardware parameters to work with your respective serial port communications software. LO100 serial port configuration is controlled through the BIOS Setup Utility.

Enabling serial access to the LO100

1. Power on the server by pressing the Power On/Off button on the front panel.
2. When POST displays the message, *ROM-Based Setup*, press the **F10** key. If the server has an administrator password configured, the system prompts you to enter the password. If the server does not have a password configured, the main screen of the BIOS Setup Utility appears.
3. On HP ProLiant ML150 G2 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to **IO Device Configuration**. Press the **Enter** key.
 - c. Select **Serial Port A**, and press the **Enter** key to toggle between Enabled and Disabled. Select **Enabled**.
 - d. Press the **Esc** key to return to the Advanced menu.
 - e. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
 - f. Press the down arrow (↓) key to scroll to the **LAN Settings** submenu. Press the **Enter** key.
 - g. Confirm the following settings:
 - Ping Response: [Enabled]
 - Telnet Access: [Enabled]
 - HTTP Access: [Enabled]
4. On HP ProLiant ML110 G3 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to navigate to the **SuperIO Configuration** menu. Press the **Enter** key.
 - c. Select **Serial Port1 Address**, and press the **Enter** key to toggle between Disabled, 3F8/IRQ4, 3E8/IRQ4, and 2E8/IRQ3. Select **3F8/IRQ4**.
 - d. Review the serial port settings, and ensure that the settings match the serial port communications software settings used to connect to LO100.
5. On HP ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to **I/O Device Configuration**. Press the **Enter** key.
 - c. Press the down arrow key (↓) to scroll to the **Serial Port** menu. Press the **Enter** key to toggle between SIO COM Port and BMC COM Port. Select **BMC COM Port**.
 - d. Press the **Esc** key to return to the Advanced menu.
 - e. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.

- f. Press the down arrow (↓) key to scroll to the **LAN Interface** submenu. Press the **Enter** key.
 - g. Confirm the following settings:
 - BMC Telnet Service: [Enabled]
 - BMC Ping Response: [Enabled]
 - BMC HTTP Service: [Enabled]
6. Press the **F10** key to save and exit.

LO100 serial port configuration

1. Power on the server by pressing the Power On/Off button on the front panel.
2. When POST displays the message, *ROM-Based Setup*, press the **F10** key. If the server has an administrator password configured, the system prompts you to enter the password. If the server does not have a password configured, the main screen of the BIOS Setup Utility appears.
3. On ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to the **Console Redirection** menu. Press **Enter**.
 - c. Press the **Enter** key to toggle between Enabled and Disabled. Select **Enabled** for the console redirection option.
 - d. Review the serial port settings, and ensure that the settings match the serial port communications software settings used to connect to LO100.
4. On ProLiant ML150 G2 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to the **Console Redirection** menu. Press **Enter**.
 - c. Press the **Enter** key to toggle between Disabled, On-board Com A, and On-board BMC/VSI. Select **On-Board BMC/VSI** for the console redirection option.
 - d. Review the serial port settings, and ensure that the settings match the serial port communications software settings used to connect to LO100.
5. On ProLiant ML110 G3 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to the **BIOS Serial Console Configuration** menu. Press the **Enter** key. Select **Bios Serial Console**, and press the **Enter** key to toggle between Enabled and Disabled. Select **Enabled**.
 - c. Press the down arrow (↓) key to scroll to and select **Serial Over LAN (SOL)**. Press the **Enter** key to toggle between Enabled and Disabled. Select **Enabled**.
6. Press the **Esc** key to return to the previous screen, or press the **F10** key to save the changes and exit Setup.

Using TCP/IP over Ethernet management port

The LO100 LAN port can be accessed from two different Ethernet ports: the dedicated 10/100 LO100 management port or through a side-band connection with the second LOM (NIC2).

Selecting an Ethernet management port

The Ethernet management port is only available on ProLiant ML150 G2 and ML110 G3 servers.

To select either the LO100 or side-band connection:

1. Power on the server by pressing the Power On/Off button on the front panel.
2. When POST displays the message, *ROM-Based Setup*, press the **F10** key. If the server has an administrator password configured, the system prompts you to enter the password. If the server does not have a password configured, the main screen of the BIOS Setup Utility appears.
3. Press the right arrow (→) key to navigate to the **Advanced** menu.
4. Press the down arrow (↓) key to scroll to NIC Option. Press the **Enter** key to select between the dedicated or side-band connection.
5. Press the **Esc** key to return to the previous screen, or press the **F10** key to save the changes and exit Setup.

The dedicated TCP/IP over Ethernet management port, whether dedicated or shared, is a standard Ethernet 10/100Mb interface that is connected to the network using a standard Ethernet cable. Before using the dedicated management port, you must determine the DHCP IP address, set a static IP address, or use the default static IP address.

Obtaining a DHCP IP address from the BIOS Setup Utility

By default, LO100 has DHCP enabled and automatically negotiates an IP address. To view the DHCP IP address, run the BIOS Setup Utility or retrieve the DHCP IP address using CLP through the serial port connection.

To view the DHCP IP address using the BIOS Setup Utility:

1. Power on the server by pressing the Power On/Off button on the front panel.
2. When POST displays the message, *ROM-Based Setup*, press the **F10** key. If the server has an administrator password configured, the system prompts you to enter the password. If the server does not have a password configured, the main screen of the BIOS Setup Utility appears.
3. Press the right arrow (→) key to navigate to the **Advanced** menu.
4. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
5. On HP ProLiant ML110 G3 and ML150 G2 servers:
 - a. Press the down arrow (↓) key to scroll to the **LAN Configuration** (ML110 G3) submenu or **LAN Interface** (ML150 G2). Press the **Enter** key.
 - b. Note the DHCP assigned IP address for future reference.
6. On HP ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the down arrow (↓) key to scroll to the **LAN Interface** submenu. Press the **Enter** key.
 - b. Note the DHCP assigned IP address for future reference.
7. Press the **Esc** key to return to the previous screen, or press the **F10** key to save the changes and exit Setup.

To configure or change your network settings, see "Network settings (on page 36)" for more information.

Setting up a static IP address from the BIOS Setup Utility

By default, LO100 has DHCP enabled and automatically negotiates an IP address.

To disable DHCP and enable a static IP address:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. On the ProLiant ML150 G2 server:
 - a. Press the down arrow (↓) key to scroll to the **LAN Interface** submenu. Press the **Enter** key.
 - b. Select **IP Address Source**, and press the **Enter** key to toggle between Enabled and Disabled. Set DHCP IP Source to **Disabled**.
 - c. Press the down arrow (↓) key to scroll to the **IP Address** setting.
 - d. Enter a valid IP address. Press the **Tab** or period (.) key to move between address fields.
 - e. Press the down arrow (↓) key to scroll down to the **Subnet Mask** submenu. Press the **Enter** key.
 - f. Enter a valid subnet mask. Press the **Tab** or period (.) key to move between address fields.
5. On the ProLiant ML110 G3 server:
 - a. Press the down arrow (↓) key to scroll to the **Set LAN Configuration** submenu. Press the **Enter** key.
 - b. Select **DHCP IP Source**, and press the **Enter** key to toggle between Enabled and Disabled. Set DHCP IP Source to **Disabled**.
 - c. Press the down arrow (↓) key to scroll to the **IP Address** submenu. Press the **Enter** key.
 - d. Enter a valid IP address, subnet mask, and gateway address. Press the **Tab** or period (.) key to move between address fields.
 - e. Press the **Esc** key to return to the **Set LAN Configuration** submenu.
 - f. Press the down arrow (↓) key to scroll to the Subnet Mask submenu. Press the **Enter** key.
 - g. Enter a valid subnet mask. Press the **Tab** or period (.) key to move between address fields.
6. On the ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the down arrow (↓) key to scroll to the **LAN Settings** submenu. Press the **Enter** key.
 - b. Set the IP Address Assignment to **Static**. This setting enables you to modify a static IP address through the BIOS setup menu.
 - c. Press the down arrow (↓) key to scroll down and enter a valid IP address, subnet mask, and gateway address (press the **Tab** or period (.) key to move between address fields).
7. Press the **F10** key to save and exit.

To restore DHCP, see "Configuring network settings using the BIOS Setup Utility (on page 37)."

Enabling telnet and HTTP services

On the ProLiant ML110 G3 server, HTTP and telnet are automatically enabled.

To enable HTTP and telnet on ProLiant DL140 G2 and ProLiant DL145 G2 servers:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.

4. Press the down arrow (↓) key to scroll to the **LAN Interface** submenu. Press the **Enter** key.
5. Press the down arrow (↓) key to scroll to the following settings, and set the parameters as needed (the following example shows configuring for LO100 access using telnet and a web page):
 - BMC Telnet Service: [Enabled]
 - BMC Ping Response: [Enabled]
 - BMC HTTP Service: [Enabled]

To enable HTTP and telnet on ProLiant ML150 G2 servers:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. Press the down arrow (↓) key to scroll to the following settings, and set the parameters as needed (the following example shows configuring for LO100 access using telnet and a web page):
 - Ping Response: [Enabled]
 - Telnet Access: [Enabled]
 - HTTP Access: [Enabled]

Updating the firmware

To update LO100 firmware, use the ROMPaq utility. ROMPaq downloads are available on the HP website (<http://www.hp.com/support>). For more information about using the ROMPaq utility, see the HP website (<http://www.hp.com/servers/manage>).

NOTE: LO100 does not support ROMPaq flashing or flashing LO100 from a virtual floppy.

NOTE: Firmware upgrade packages for ProLiant ML150 G2 servers contain firmware images for LO100 standard and advanced functionality. When updating the firmware, only the active LO100 device is flashed. If an HP Lights-Out 100c Remote Management Card is installed in the system when flashing the firmware, only the HP Lights-Out 100c Remote Management Card firmware is updated. If an HP Lights-Out 100c Remote Management Card is not installed, only the standard (basic) LO100 functionality is updated.

After the ROMPaq utility flashes the selected device, cycle power manually to reboot the operating system.

Updating the firmware remotely

If you want to update the LO100 firmware remotely, you can use the `load` command. The firmware file must be an uncompressed firmware image file which you can create using the DOS ROMPAQ utility found on the Lights-Out 100 Firmware Upgrade Diskette Utility, available for download from the HP website (<http://www.hp.com/servers/lights-out>).

To create an uncompressed image file, enter the following command at the DOS prompt:

```
ROMPAQ /D <infile> <outfile>
```

where <infile> is the ROMPAQ firmware image file and <outfile> is the file name for the uncompressed binary image file. For example:


```
ROMPAQ /D cpqq0801.D14 ldrImage.bin
ROMPAQ Firmware Upgrade Utility, Version 5.02 (R)
Copyright (c) Hewlett-Packard Corporation, 1994-2006
Input file: CPQQ0801.D14
Output file: LDRIMAGE.BIN
```

The `load` command is used to take a binary image from a specific source location (specified as a URL) and place it at the specified target address. The `load` command can download and flash a `ldr` firmware image file using TFTP from the specified location.

To update the firmware, log in to LO100 as administrator through the CLP interface and issue the `load` command to upload and install the firmware from the `map1/firmware` directory.

1. Start a CLP session. To access the CLP in Windows®:
 - a. Click **Start>All Programs>Accessories>Command Prompt**.
 - b. At the command prompt, enter `telnet <IP address>` where `IP address` is the IP Address of the server to which you want to connect.
2. At the CLP prompt, enter: `cd/map1/firmware`
3. At the CLP prompt, enter `load -source <URI> -oemhpfiletype csr`
where:
 - o `<URI>` is the `//tftpserver IP/path/filename` to be downloaded.
 - o `tftp server IP` is the URL or IP address of the TFTP server containing the firmware.
 - o `filename` is the file name of the image file (`ldrImage.bin` in this example).

For example, enter: `load -source //10.141.38.157/LdrImage.bin - oemhpfiletype csr`

NOTE: After using the `load` command LO100 will reset ending your CLP interface session. You must reconnect to the CLP interface.

NOTE: When you use the CLP `load` command with TFTP32, HP recommends using a 30-second timeout and 6 retries.

TFTP settings

When using a TFTP server, the settings vary by on different operating systems. Use the following settings:

Flashing the firmware image file using TFTP on Microsoft Windows®

1. Copy the BMC firmware into a directory on the server.
2. Run TFTP by launching the executable file `tftpd32.exe`.
3. Navigate to **TFTP Configuration>Settings**, and set Timeout to **30 seconds** and Max Retransmit to **6**.
4. Enter **File Name** and **TFTP Server IP Address**. File Name is the path where the BMC firmware is residing. TFTP Server IP Address is the IP address of the TFTP server. For example, 10.141.38.157.

Flashing the firmware image file using TFTP on Linux

1. Navigate to **Applications>Systems Settings>Server Settings>Services**, and ensure that `tftp` and `xinetd` are running.

2. Open the file `/etc/xinetd.d/tftp` and modify the parameter `server_args` to include `-T 15000000`. For example, `server_args = -c -s /tftpboot -T 15000000`
3. The firewall that is built into some Linux systems might not allow the TFTP server to send and receive information. You might first have to disable the firewall to allow these connections. If you are experiencing firewall issues, change the firewall settings to allow connections on port 69 (the default port for TFTP servers). See your firewall documentation for additional information.

If a firewall is enabled, disable it or modify the settings to allow the firewall to connect to the TFTP port. To change the firewall settings, navigate to **Applications>System Settings>Security Level**, and enter **69:udp** in other ports.

Using LO100

In this section

SSL overview	19
SSH overview	20
Importing a certificate	21
CLP overview	22
IPMI 2.0 support	27
Logging in to LO100	28
Browser main menu options	29
Hardware Inventory page	30
Controlling server power remotely	30
Monitoring sensors	32
Using the system event log	34
Network settings	36
Using the virtual floppy feature	38
Platform event trap configuration	41
User administration	42
Accessing the remote console through telnet	43
HP SIM support	46

SSL overview

SSL is an advanced feature that is available on ProLiant ML150 G2 and ProLiant ML110 G3 servers by installing the Lights-Out 100 Remote Management Card, or on ProLiant DL140 G2 servers and ProLiant DL145 G2 servers by purchasing the Lights-Out 100i Select Pack or the Lights-Out 100i Advanced Pack.

SSL is a protocol used to transmit private documents through the Internet. SSL uses a private key or certificate to encrypt data transferred over the SSL connection. The Lights-Out 100 remote management processor provides strong security for remote management in distributed IT environments by using 128-bit SSL encryption of HTTP data transmitted across the network. SSL encryption ensures that the HTTP information is secure as it travels across the network.

LO100 comes preinstalled with a certificate. To install a user-specific certificate, see the one-time "Importing a certificate (on page 21)" setup procedure.

If you cannot access the login page, you must verify the SSL encryption level of your browser is set to 128 bits. The SSL encryption level within the management processor is set to 128 bits and cannot be changed. The browser and management processor encryption levels must be the same.

To use the preinstalled certificate, enter `https://ipaddress` in the address line of the browser, which uses SSL-encrypted communication. Enter `http://ipaddress` to use non-SSL encrypted communication.

SSH overview

SSH is an advanced feature that is available on ProLiant ML150 G2 and ProLiant ML110 G3 servers by installing the Lights-Out 100 Remote Management Card, or on ProLiant DL140 G2 servers and ProLiant DL145 G2 servers by purchasing the Lights-Out 100i Select Pack or the Lights-Out 100i Advanced Pack.

SSH is a telnet-like program for logging in to and executing commands on a remote machine, which includes security with authentication, encryption, and data-integrity features. The Lights-Out 100 remote management processor can support simultaneous access from two SSH clients. After SSH is connected and authenticated, the command line interface is available.

LO100 supports the following protocols:

- SSH protocol version 2
- PuTTY 0.54, which is a free version of telnet and SSH protocols available for download on the Internet. When using PuTTY, versions earlier than 0.54 might display two line feeds instead on a single line feed, when the **Enter** key is pressed. To avoid this issue, and for best results, use version 0.54 or later.
- OpenSSH, which is a free version of the SSH protocol available for download on the Internet.

NOTE: Logging in to an SSH session could take up to 90 seconds. Depending on the client used, you might not see on-screen activity during this time.

LO100 comes preinstalled with a certificate. To install a user-specific certificate, see the one-time "Importing a certificate (on page 21)" setup procedure.

Using SSH

When using a Secure Shell utility to connect to a server for the first time, the utility will prompt you to accept the server's public key, sometimes referred to as a host key. Accepting this key authorizes the utility to store a copy of the public key in its own database. The utility will automatically recognize the server when future connections are attempted, by comparing the public key to the one stored in its database.

To access the remote management processor using SSH:

1. Open an SSH window.
2. When prompted, enter the IP address or DNS name, login name, and password.

Using OpenSSH

To start an OpenSSH client in Linux, use:

```
ssh -l loginname ipaddress/dns name
```

Using PuTTY

- To start a PuTTY session, double-click the PuTTY icon in the directory in which PuTTY is installed.
- To start a PuTTY session from the command line:
 - To start a connection to a server called *host*:
`putty.exe [-ssh | -telnet | -rlogin | -raw] [user@]host`
 - For telnet sessions, the following alternative syntax is supported:
`putty.exe telnet://host[:port]/`
 - To start an existing saved session called *sessionname*:

- o `putty.exe -load "session name"`

Importing a certificate

If you do not want to use the preinstalled public key (certificate), create and install your own private key (certificate). Importing a key or certificate is a one-time procedure that supports both SSH and SSL. The key must be generated using external third-party software, placed on a TFTP server, and uploaded to the LO100. For Microsoft® Windows®, if you do not have a TFTP software package, use TFTP32.EXE, which is available on the Internet. Linux generally has a TFTP server installed with the operating system. If it is not, see your Linux documentation for more information.

NOTE: When you use the CLP `load` command with TFTP32, HP recommends using a 30-second timeout and 6 retries.

NOTE: When using the CLP `load` command in Linux set the timeout to 15000000. The firewall built into some Linux systems might not allow the TFTP server to send and receive information. You might have to disable the firewall to allow these connections. If you are experiencing firewall issues, change the firewall settings to allow connections on port 69 (the default port for TFTP servers). See your firewall documentation for additional information.

Creating a certificate

LO100 requires a 1,024-bit DSA key stored in PEM (Base64-encoded) format to be located on a TFTP server. For example, the following process uses Win32 OpenSSL, downloaded from the Shining Light Productions website (<http://www.slproweb.com/products/Win32OpenSSL.html>), with the commands issued in a DOS window to generate the certificate. To generate a certificate using Win32 OpenSSL:

1. Download Win32 OpenSSL.
2. Install and set up OpenSSL.
3. Using OpenSSL, generate a DSA parameters file:

```
openssl dsaparam -out server_dsaparam.pem 1024
```
4. Generate the DSA private key file, called `server_privkey.pem`:

```
openssl gendsa -out server_privkey.pem server_dsaparam.pem
```
5. Generate the DSA certificate (public key) file, called `server_cacert.pem`:

```
openssl req -new -x509 -key server_privkey.pem -out server_cacert.pem -days 1095
```
6. When prompted for a distinguished name, enter an appropriate domain name for the servers receiving the certificate.
7. After creating the certificate, copy it to a TFTP server that is accessible on the same network as LO100.

Installing a certificate or private key through the CLP

To install the certificate, log in to LO100 as administrator through the CLP interface and issue the `load` command to upload and install the certificate. For example:

```
load -source <URI> -oemhpfiletype cer
```

where:

- <URI> is the //tftpserver IP/path/filename to be downloaded.
- tftpserver is the URL or IP address of the TFTP server containing the certificate.
- Path is the path of the file relative to the TFTP server root.
- filename is the name of the certificate (server_privkey.pem in this example).

You can also find these commands in /map1/firmware directory.

To install a private key, log in to LO100 as administrator through the CLP interface, and issue the load command to upload and install the certificate. For example:

```
load -source <URI> -oemhpfiletype key
```

where:

- <URI> is the //tftpserver IP/path/filename to be downloaded.
- tftpserver is the URL or IP address of the TFTP server containing the private key file.
- Path is the path of the file relative to the TFTP server root.
- filename is the file name of the private key file (server_privkey.pem in this example.)

You can also find these commands in /map1/firmware directory.

NOTE: After using the load command LO100 will reset ending your CLP interface session. You must reconnect to the CLP interface.

CLP overview

HP has worked with key industry partners within Distributed Management Task Force, Inc. to define an industry-standard set of commands. The SMASH suite will standardize manageability interfaces for servers. The Lights-Out 100 remote management processor implements the command set defined in the *Server Management Command Line Protocol Specification, 1.00 Draft*. The CLP replaces the simple CLI that was released previously and is no longer supported.

The management processor functionality accessible from the SMASH CLP is a low-bandwidth interface and provides similar functionality to the web interface. The CLP is designed for users who prefer a nongraphical interface. The CLP is accessible through the following methods:

- Telnet
- SSH connection
- Physical serial port

Using CLP

The general syntax of CLP command is:

```
<verb> <target> <option> <property>
```

- **Verbs**—The following verbs are supported:
 - cd
 - help
 - load
 - reset
 - set

- show
- start
- stop
- exit
- version
- **Target**—The default target is the `/`. The target can be changed by the `cd` command or by specifying a target on the command line.
- **Options**—The following options are valid:
 - `-help/-h`
 - `-all/-a`
- **Properties** are the attributes of the target that can be modified.
- **Output**—The output syntax is `text`.

The valid Boolean values for any command are `true` and `false`.

General notes

If the commands on the CLP command span more than one line, you cannot navigate between different lines.

Operating system-specific notes

- The Microsoft® Windows® 2000 telnet client does not support the Functions keys F1 through F12, Insert, Home, and End keys. These keys will not work in a Lights-Out 100 command line session.
- The Backspace key in the Lights-Out 100 CLP implementation is mapped to the value `0x8`. Some client operating systems, Novell Linux Desktop and Red Hat Enterprise Linux 4 Desktop, map the Backspace key to the value `0x7f`, which is used for the Delete key in the Windows® telnet client. The Backspace key will not work from a client from which it has value of `0x7f`. For the Linux clients, using the Home or the End key enables the Lights-Out 100 CLP service to remap the Backspace key to use the value `0x7f`, making the key functional.

In the Windows® PuTTY client, the Backspace key can be mapped to a value of `0x8` by changing the setting for Terminal Keyboard to Control-H.

Base commands

- The `help` command displays context-sensitive help.

Entering `help` displays all the supported commands. Entering `<command help/?>` displays the help message specific to that command.

 - Help for verbs

Calling help for a verb returns the general syntax and usage associated with issuing that verb. Calling help for a verb that is not present in the current directory returns an `Unsupported Command` message. The following are all valid ways to call help for a verb.

```
./-> help show
Usage: show [<target>] [<options>] [<properties>]
```

```
./-> show -h
Usage: show [<target>] [<options>] [<properties>]
```

```
./-> show -help
Usage: show [<target>] [<options>] [<properties>]
```

```
./->
```

- o Help for targets

Calling help for a target returns any information about the target and what it contains. You can call help for any target that is not contained in the current directory (help map1 can be called from system1).

```
./-> system1 -h
Invalid command
```

```
./-> system1 -help
Invalid command
```

```
./-> help system1
Host System Directory
```

```
./-> help map1
Management Service Processor Directory
```

```
./-> cd system1
```

```
./system1/-> help map1
Management Service Processor Directory
```

- o Help for properties

Calling help for a property or any other option for which there is no help information returns an Unsupported Command or Invalid command message. For example:

```
./system1/-> show
./system1
Targets
    log1
```

```
Properties
    name=Hewlett-Packard
    enabledstate=enabled
```

```
Verbs
    cd
    version
    exit
    show
    reset
    start
```



```
stop
help
```

```
./system1/-> help name
Unsupported Command
```

```
./system1/-> help enabledstate
Unsupported Command
```

```
./system1/-> help properties
Unsupported Command
```

```
./system1/-> name -h
Invalid command
```

```
./system1/->
```

- The `exit` command terminates the CLP session.
- The `cd` command sets the current default target. The context works like a directory path. The root context for the server is `/.` which is the starting point for a CLP system. By changing the context, you can shorten commands.

For example:

- `cd` changes the directory.
- `cd ..` moves up the tree one directory.
- `cd folder` moves to folder assuming folder is in the current directory.

If you want to move to a directory not in the current directory, you must enter the full path. Root in the command line is `./`

If you are in `system1` and want to move to `map1`, issue the command `cd ../map1`. Neither `cd /map1` nor `cd map1` works. The filename is not case-sensitive, whereas the command is case-sensitive (`cd MaP1` works while `CD map1` does not).

- The `show` command displays values of a property or contents of a collection target. For example:
`./> show`

```
./
Targets
  system1/
  map1/
Properties
Verbs
  cd
  version
  exit
  show
  help
```

The first line of information returned by the `show` command is the current context. In the example, `/` is the current context. Following the context is a list of subtargets (Targets) and properties (Properties) applicable to the current context. The verbs (Verbs) section shows what commands are available in this context.

The `show` command can also be specified with an explicit or implicit context and a specific property. An explicit context is `/map1/firmware` and is not dependent on the current context. An implicit context assumes that the context specified is a child of the current context. If the current context is `/map1`, then a `show firmware` command displays the `/map1/firmware` data. If a property is not specified, then all properties are shown.

- The `load` command moves a binary image from a URL to the map. The `load` command is used to take a binary image from a specific source location (specified as a URL) and place it at the specified target address. In a remote management processor implementation, the firmware downloads a full image file using TFTP from the specified location and programs flash with the image.

In a remote management processor implementation, `/map1/firmware` is a valid target.

The `load` command supports usage only with the following options.

- `-source <location>`—This option must be specified.
- `(h)elp`—this option appears on the command line, the command ignores all options and properties except `-output` (for terse or verbose output). These options are only valid for this command when the `-help` option is used.
- `source <value>`—This option specifies the target from which it will transfer the binary image. The value specified must be a valid URL. The expected format is `//tftpserverip/path/filename`. This option is required in the command line every time the `load` command is executed unless `-help` is used. The file must be an uncompressed firmware image file that you create using the DOS ROMPAQ utility found on the Lights-Out 100 Firmware Upgrade Diskette Utility available for download from the HP website (<http://www.hp.com/servers/lights-out>).

To create the uncompressed image file, enter the following command from DOS:

```
ROMPAQ /D <infile> <outfile>
```

where `<infile>` is the ROMPAQ firmware image file and `<outfile>` is the filename for the uncompressed binary image file.

The `load` command returns any status data on the first lines. After the status data appears, one of the following lines of text displays on the next line:

```
<URL> transferred to <target address> (if the file is transferred)
```

```
<URL> not transferred (if the file is not transferred)
```

Example:

```
load -source //192.168.2.1/pub/firmwareimage.bin -oemhpfiletype csr
//192.168.2.1/pub/firmwareimage.bin transferred to
/map1/firmware/fullimage
```

- The `reset` command causes a target to cycle from enabled to disabled and back to enabled.
- The `set` command sets a property or set of properties to a specific value. `set property = new value` is the standard syntax for the `set` command.

The `set` command is used to change any changeable property. If the current directory does not contain the property you want to change, the target of the property must be specified before entering the property you want to change.

- The `start` command causes a target to change state to a higher run level.
- The `stop` command causes a target to change state to a lower run level.
- The `version` command queries the version of the CLP implementation or other CLP elements. For example:

```

./map1/-> version
Version 1.00

./map1/-> cd firmware
./map1/firmware/-> version
Version 1.00

./map1/firmware/-> show
./map1/firmware
Targets
Properties
    fwversion=0.59
Verbs
    cd
    version
    exit
    show
    reset
    load
    help
./map1/firmware/-> show fwversion
fwversion=0.59

./map1/firmware/-> fwversion
Invalid command

./map1/firmware/->

```

Specific commands

CLP syntax for specific commands is found in the sections that also describe the functionality through the Web interface.

IPMI 2.0 support

LO100 supports the industry-standard IPMI 2.0. The IPMI specification defines standardized, abstracted interfaces that can be used for monitoring and control functions that are built in to the platform hardware.

In addition to supporting the mandatory commands for IPMI 2.0, the following additional IPMI 2.0 features are supported by LO100:

- Additional IPMI 2.0 commands
 - Get Channel Cipher Suites
 - Set/Get Channel Security Keys
 - Suspend/Resume Payload Encryption

- Payload types
 - IPMI Message
 - RMCP+ Open Session Request/Response
 - RAKP Message 1 / 2
 - RAKP Message 3 / 4
- Authentication algorithms
 - RAKP-none
 - RAKP-HMAC-SHA1
- Integrity algorithms
 - None
 - HMAC-SHA1-96
- Confidentiality algorithms
 - None
 - AES-CBC-128

Logging in to LO100

You can log in to the remote management processor through a web browser ("[Logging in through a web browser](#)" on page 28) or through the CLP ("[Logging in through the CLP](#)" on page 29). If you are unsure of your DHCP IP address, refer to the "Configuring network access (on page 11)" section.

Logging in through a web browser

1. Browse to the IP address of the remote management processor to access the login screen.
2. Enter your user name and password. The default user name for the Administrator account is admin, and the default password is admin. The default user name for the Operator account is Operator, and the default password is Operator.



Enter Network Password

This secure Web Site (at xx.xxx.xxx.x) requires you to log on.

Please type the User Name and Password that you use for BMC.

User Name: admin

Password: [masked]

Save this password in your password list

OK Cancel

Logging in through the CLP


To log in to the remote management processor through the CLP and enter Terminal mode:

1. Establish a connection to the remote management processor by launching a telnet session or an SSH session.
2. Enter the user name at the login: prompt. The default user name for the Administrator account is admin. The default user name for the Operator account is Operator.
3. Enter the password at the password: prompt. The default password for the Administrator account is admin. The default password for the Operator account is Operator.

To exit the CLP and enter Console mode, enter the `exit` command at the command prompt.

Browser main menu options

The main menu provides access to all basic remote management capabilities of the remote management processor.



Option	Description
Home	Accesses or returns you to the main menu navigation bar
Virtual Power	Accesses system power control options
Monitoring Sensors	Lists all sensor information, including type, name, status, reading, and PEF settings
System Event Log	Displays the system event log
Virtual Floppy	Accesses the virtual floppy screen
Hardware Inventory	Displays system hardware
User Administration	Accesses the user configuration screen
Network Settings	Accesses the network parameter settings screen

Option	Description
IPMI PET Configuration	Accesses the PET destinations and alert policy table

Hardware Inventory page

The Hardware Inventory page enables you to remotely identify the presence of processors on a target server. To access this page from a web browser, click **Hardware Inventory** on the main menu navigation bar.



The screenshot shows a web browser window with a blue "Home" link at the top. Below it is the title "Hardware Inventory" in blue. A table displays sensor information:


Sensor Type	Sensor Name	Sensor Status
Processor	CEU0 SocketOcc	Device Present
Processor	CEU1 SocketOcc	Device Present

Controlling server power remotely

LO100 enables you to remotely operate the power button of a host server using a web browser or the CLP. LO100 virtual power support enables you to power up, power down, and power cycle the host server. This virtual power support operates independently of the state of the operating system.

Controlling server power from a browser

The Virtual Power screen displays current power status, how long the server has been powered up, and reason for the last server restart. To display the Virtual Power screen, click **Virtual Power** on the main menu navigation bar.



To modify Chassis Actions, select the desired Power Control Option in the Chassis Actions section, and click **Apply** to initiate the action.

To identify the server in the rack and illuminate the UID (LED on the front panel of the server), select the length of time you want the UID to stay illuminated on the Chassis Locator list, and click **Identify**.

NOTE: The UID is only available on HP ProLiant DL140 G2 and ProLiant DL145 G2 servers.

Controlling server power through the CLP

1. Log in to LO100 CLP as described in the "Logging in to LO100 (on page 28)" section.
2. Change to the system1 target by entering `cd system1`.
3. To power on the server, enter `start /system1`. For example:

```
./system1/> start /system1  
System1 started.
```
4. To power off the server, enter `stop /system1`. For example:

```
./system1/> stop /system1  
System1 stopped.
```

The `-force` option can also be used with the `stop` command. This option forces the implementation to stop the target, ignoring any policy that might cause the implementation to normally not execute the command. In remote management processor implementation, this process is equivalent to a hard power down.

5. To reset the server, enter `reset /system1`. For example:

```
./system1/> reset  
System1 reset.
```

Controlling server power through the BIOS Setup Utility

To control how the system responds after a power failure through the BIOS Setup Utility:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the Power Tab of the BIOS Setup Utility.
3. Press the down arrow (↓) key to scroll down to After Power Failure. Press the **Enter** key.
4. On the ProLiant ML150 G2, or ML110 G3 servers: Use the arrow keys to navigate between Stay Off, Last State, and Power On. Select your power control option, and press the **Enter** key.
5. On ProLiant DL140 G2 or ProLiant DL145 G2 servers: Use the arrow keys to navigate between Always Off, Previous State, and Always On. Select your power control option, and press the **Enter** key.
6. Press the **F10** key to save and exit.

Monitoring sensors

LO100 provides operating system-independent remote monitoring of the current status of major sensors of a target server including system temperature, fans, and voltage. You can view the data for this feature on the Monitoring Sensors Page through a web browser or through the BIOS Setup Utility.

Viewing sensors data from a web browser

The Monitoring Sensors screen displays a snapshot of the temperature, fans, and voltage sensor data including sensor type, name, status, and current reading. To access this page from a web browser, click **Monitoring Sensors** on the main menu navigation bar.



The screenshot shows a web browser window with a navigation bar at the top containing a "Home" link. Below the navigation bar is the title "Monitoring Sensors". The main content is a table with the following columns: Sensor Type, Sensor Name, Sensor Status, Current Reading, and a PEF button. The table contains 16 rows of sensor data.

Sensor Type	Sensor Name	Sensor Status	Current Reading	PEF
Sys. ACPI Pwr. State	ACPI State	S0 Power State	1	PEF
Module/Board	System Reset	Lpc Deasserted	0	PEF
Fan	CPU0 Fan	Normal operating range	2580 RPM	PEF
Fan	CPU1 Fan	Unavailable		PEF
Fan	PCI Fan	Normal operating range	1395 RPM	PEF
Fan	Rear Fan	Normal operating range	1297 RPM	PEF
Voltage	System 12V	Normal operating range	12.208 Volts	PEF
Voltage	System 5V	Normal operating range	5.06 Volts	PEF
Voltage	System AUX 5V	Normal operating range	4.991 Volts	PEF
Voltage	System 3.3V	Normal operating range	3.285 Volts	PEF
Voltage	System AUX 3.3V	Normal operating range	3.285 Volts	PEF
Voltage	CPU0 Vcore	Normal operating range	1.27 Volts	PEF
Voltage	CPU1 Vcore	Unavailable		PEF
Voltage	CPU Vmem	Normal operating range	1.25 Volts	PEF
Voltage	Memory Vcore	Normal operating range	1.84 Volts	PEF

To update the display, click the **Refresh** button on the web browser. To view or add a PEF action, click **PEF**. See "Platform Event Filtering configuration (on page 33)" for more information.

Viewing sensors data from the BIOS Setup Utility

1. Press the **F10** key during POST to enter the BIOS Setup Utility.

2. On ProLiant ML150 G2 servers:
 - a. To navigate to the **Monitor** menu, press the right arrow (→) key.
 - b. Scroll down to view the different sensors. Data is real-time and updated periodically.
3. On ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
 - c. Press the down arrow (↓) key to scroll to **Realtime Sensor Data**. Press the **Enter** key.
The Loading data. Please wait... message appears. After this message disappears, the Temperature and Voltage sensor data appears. Data is displayed in real-time and updated periodically.
4. On the ProLiant ML110 G3 server:
 - a. Press the right arrow (→) key to navigate to the **Advanced** menu.
 - b. Press the down arrow (↓) key to scroll to **Hardware Health Configuration** menu. Press the **Enter** key. The real-time sensor data displays.

Platform event filtering configuration

The PEF Configuration screen enables you to configure LO100 to take selected actions on received or internally generated event messages. These actions include powering down the system, system reset, and triggering the generation of an alert.

To configure a PEF for a particular sensor, click the **PEF** button to the far right of that sensor on the Monitoring Sensors screen. The PEF button adjacent to each sensor opens a PEF Configuration page for that sensor.

The PEF Configuration screen contains two sections: Current PEF Entries and Add PEF Entry. The Current PEF Entries section includes Sensor Type, Sensor Name, PEF Action, and PEF Control information. The Add PEF Entry section enables you set an action.

Initially, there are no entries in the Current PEF Entries section because no PEFs are defined. When PEF entries are defined, the PEF Control field is active and allows individual entries to be enabled, disabled, or deleted.

The screenshot shows the PEF Configuration interface. At the top, there is a 'Home' link and the title 'PEF Configuration'. Below this, there are two main sections:

Current PEF Entries: A table with columns for Sensor Type, Sensor Name, PEF Action, and PEF Control. The table is currently empty.

Add PEF Entry: This section includes a grid of checkboxes for various sensors, such as S0 Power State, S1 Power State, S2 Power State, S3 Power State, S4 Power State, S5 Power State, SoICM Power State, G3 Power State, Sleep Power State, G1 Power State, SOverride Power State, S_ON Power State, S_OFF Power State, and Unknown Power State. Below the grid is a 'PEF Action' section with a table for defining actions. The table has columns for Sensor Type, Sensor Name, PEF Action, and PEF Control. An example entry is shown: Sensor Type: Sys. ACPI Power State, Sensor Name: ACPI State, PEF Action: Power Off, PEF Control: Enabled. There is also a 'No Alert Policy' checkbox and an 'Add' button.

To configure an action (PEF entry) select the desired Event Offsets and PEF Action settings and click **Add**.

- Event Offsets are trip points (movements across thresholds) that define what type of sensor event triggers an action. The information in the Events Offsets section varies with the type of sensor. Not all options are available for all sensors. You can select any of the available options.
- PEF Action displays the same information for all sensors:
 - Sensor Type displays the type of sensor selected.
 - Sensor Name displays the name of the sensor.
 - PEF Action enables you to select from Power Off, Power Cycle, Hard Reset, and Send Alert (requires a systems management console supporting IPMI 1.5 or later.)
 - PEF Control enables or disables the sensor.
 - Alert Policy (dropdown list adjacent to the Add button) enables you to select an alert policy (if defined.) Alert policies are defined on the PET Configuration screen. See "Platform event trap configuration (on page 41)" for more information.


If alert policies are not defined (default), the Alert Policy dropdown list displays No Alert Policy. The Alert Policy dropdown list will populate after alert policies are defined and configured. After configuring your alert policies, you can select from the defined alert policies for this sensor and PEF.
 - Add adds the new entry to the PEF Current Entry table at the top of the page.

Using the system event log

LO100 captures and stores the IPMI event log for access through a browser, CLP, BIOS Setup Utility, and RBSU even when the server is not operational. The system event log lists a short description of each system event. Recorded events include abnormal temperature, fan and voltage events, system resets, system power loss, user login, and unsuccessful login attempts.

Accessing the system event log from a web browser

The System Event Log screen displays a brief description of the event including event type, date, time, source, description, and direction.



Event Type	Date	Time	Source	Description	Direction
Generic	06/23/2006	11:05:38	RCP01 Diode 1	Upper Critical-going low	Deassertion
Generic	06/23/2006	11:05:38	RCP01 Diode 1	Upper Critical-going high	Assertion
Generic	06/23/2006	11:05:38	RCP01 Diode 2	Upper Critical-going low	Deassertion
Generic	06/23/2006	11:05:38	RCP01 Diode 2	Upper Critical-going high	Assertion

To access the System Event Log from a web browser, click **System Event Log** on the main menu navigation bar. To clear the system event log, click **Clear Event Log**.

Accessing the system event log from the CLP

1. Log in to the CLP as described in the "Logging in to LO100 (on page 28)" section.
2. Enter `cd ../system1/log1`
3. Enter `show` to display the total number of system event records.
4. Enter `show record<n>` to display the details of a specific record. For example:

```
/system1/log1/record1
Targets
Properties
    number=1
    date=12/20/2004
    time=15:22:05
    sensordescription= Backplane +12V
    eventdescription= Upper Critical-going high
    eventdirection=Assertion
Verbs
    cd
    version
    exit
    show
    reset
    oemhp
    help
```

Accessing the system event log from the BIOS Setup Utility

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. On ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the down arrow (↓) key to scroll to **System Event log** submenu. Press the **Enter** key.
 - b. Press the down arrow (↓) key to scroll the following setup options: Clear System Event Log and View System Event Log.

If you select **View System Event log**, use the PG UP, PG DOWN keys, or spacebar to scroll through the entries.
5. On ProLiant ML150 G2 servers:
 - a. Press the down arrow (↓) key to scroll to the **System Event log** submenu. Press the **Enter** key.
 - b. Press the down arrow (↓) key to scroll to through the following setup options including Date Format to show, Date Separator, System Event Logging, Sys Firmware Progress, and BIOS POST Errors.
6. On ProLiant ML110 G3 servers:

- a. Press the down arrow (↓) key to scroll to the **View BMC System Event Log** submenu. Press the **Enter** key.
 - b. Use the plus (+) or minus (-) keys to scroll through the events.
7. Press the **Esc** key to return to the previous screen, or press the **F10** key to save the changes and exit Setup.

Network settings

You can view and modify network settings for LO100 using a web browser, CLP, or the BIOS Setup Utility. If you change the IP address, the connection to the server terminates. You must reconnect to the server using the new IP address.

Configuring network settings using a web browser

The Network Settings screen displays IP address, subnet mask, and other TCP/IP-related settings. From the Network Settings screen, you can enable or disable DHCP, and you can configure a static IP address for servers not using DHCP. You can view and modify the network settings when logged in as either OEM or administrator (admin).

Standard Configuration Parameters	
MAC Address	00:c0:d1:00:eb:d3
IP Address	16.100.000.00
Subnet Mask	255.255.000.0
Gateway	16.100.000.1
DHCP	<input type="checkbox"/> Enabled
<input type="button" value="Apply"/>	

To modify the network settings, click **Network Settings** on the browser main menu navigation bar, enter the new settings, and click **Apply**.

Configuring network settings using the CLP

1. Log in to LO100 CLP as described in the "Logging in to LO100 (on page 28)" section.
2. At the command prompt, enter `cd map1/nic1`.
3. Configure the network settings by entering the following: `set <network property>=<new setting>`. Configurable valid network properties are:
 - o `networkaddress` specifies the IP address for the NIC. This setting is dynamic.
 - o `oemhp_nonvol_networkaddress` specifies the IP address stored in non-volatile memory.
 - o `oemhp_mask` specifies the subnet mask for NIC. This setting is dynamic.

- o `oemhp_nonvol_mask` specifies the subnet mask stored in non-volatile memory.
- o `oemhp_gateway` specifies the gateway IP address for the NIC. This setting is dynamic.
- o `oemhp_nonvol_gateway` specifies the gateway IP address stored in non-volatile memory.
- o `oemhp_dhcp_enable` specifies whether DHCP is enabled for the NIC. Boolean values are accepted
- o `oemhp_nonvol_dhcp_enable` specifies whether DHCP is enabled for the NIC and address stored in non-volatile memory.

Configuring network settings using the BIOS Setup Utility

To enable a static IP address:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. On the ProLiant ML150 G2 server:
 - a. Press the down arrow (↓) key to scroll to the **LAN Interface** submenu. Press the **Enter** key.
 - b. Select **IP Address Source**, and press the **Enter** key to toggle between Enabled and Disabled. Set DHCP IP Source to **Disabled**.
 - c. Press the down arrow (↓) key to scroll to the **IP Address** setting.
 - d. Enter a valid IP address. Press the **Tab** or period (.) key to move between address fields.
 - e. Press the down arrow (↓) key to scroll down to the **Subnet Mask** submenu. Press the **Enter** key.
 - f. Enter a valid subnet mask. Press the **Tab** or period (.) key to move between address fields.
5. On the ProLiant ML110 G3 server:
 - a. Press the down arrow (↓) key to scroll to the **Set LAN Configuration** submenu. Press the **Enter** key.
 - b. Select **DHCP IP Source**, and press the **Enter** key to toggle between Enabled and Disabled. Set DHCP IP Source to **Disabled**.
 - c. Press the down arrow (↓) key to scroll to the **IP Address** submenu. Press the **Enter** key.
 - d. Enter a valid IP address, subnet mask, and gateway address. Press the **Tab** or period (.) key to move between address fields.
 - e. Press the **Esc** key to return to the **Set LAN Configuration** submenu.
 - f. Press the down arrow (↓) key to scroll to the Subnet Mask submenu. Press the **Enter** key.
 - g. Enter a valid subnet mask. Press the **Tab** or period (.) key to move between address fields.
6. On the ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the down arrow (↓) key to scroll to the **LAN Settings** submenu. Press the **Enter** key.
 - b. Set the IP Address Assignment to **Static**. This setting enables you to modify a static IP address through the BIOS setup menu.
 - c. Press the down arrow (↓) key to scroll down and enter a valid IP address, subnet mask, and gateway address (press the **Tab** or period (.) key to move between address fields).
7. Press the **F10** key to save and exit.

To enable a DHCP assigned address:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.

2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. On the ProLiant ML150 G2 server:
 - a. Press the down arrow (↓) key to scroll to the **Set LAN Interface** submenu. Press the **Enter** key.
 - b. Select **DHCP IP Source**, and press the **Enter** key to toggle between Enable and Disabled. Select **Enabled**.
5. On the ProLiant ML110 G3 server:
 - a. Press the down arrow (↓) key to scroll to the **Set LAN Configuration** submenu. Press the **Enter** key.
 - b. Select **DHCP IP Source**, and press the **Enter** key to toggle between Enable and Disabled. Select **Enabled**.
6. On HP ProLiant DL140 G2 and ProLiant DL145 G2 servers:
 - a. Press the down arrow (↓) key to scroll to the **LAN Settings** submenu. Press the **Enter** key.
 - b. Set the IP Address Assignment to **DHCP**.
7. Press the **F10** key to save and exit.

On the ProLiant ML110 G3 server, HTTP and telnet are automatically enabled.

To enable HTTP and telnet on ProLiant DL140 G2 and ProLiant DL145 G2 servers:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. Press the down arrow (↓) key to scroll to the **LAN Interface** submenu. Press the **Enter** key.
5. Press the down arrow (↓) key to scroll to the following settings, and set the parameters as needed (the following example shows configuring for LO100 access using telnet and a web page):
 - o BMC Telnet Service: [Enabled]
 - o BMC Ping Response: [Enabled]
 - o BMC HTTP Service: [Enabled]

To enable HTTP and telnet on ProLiant ML150 G2 servers:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
4. Press the down arrow (↓) key to scroll to the following settings, and set the parameters as needed (the following example shows configuring for LO100 access using telnet and a web page):
 - o Ping Response: [Enabled]
 - o Telnet Access: [Enabled]
 - o HTTP Access: [Enabled]

Using the virtual floppy feature

The virtual floppy feature enables you to boot the server with a boot image residing on a remote server. To boot using a virtual floppy on a remote system:

1. Configure the TFTP server ("[Configuring the TFTP Server](#)" on page 39).

2. Configure the virtual floppy on the server using one of the following methods:
 - o BIOS Setup ("Configuring the virtual floppy from the BIOS setup" on page 40)
 - o Web browser ("Configuring virtual floppy from a Web browser" on page 39)
 - o CLP ("Configuring virtual floppy from the CLP" on page 40)
3. Reboot the server ("Rebooting the server" on page 41).

Configuring the TFTP Server

The virtual floppy feature enables you to boot the server with a boot image residing on a remote server. To boot using a virtual floppy on a remote system:

1. Install a TFTP server on a remote system and ensure that it is running. (TFTP servers are typically included with Linux and are available for other operating systems as well. Consult your TFTP server documentation for further details. If you do not have a TFTP software package, use TFTP32.EXE, which is available on the Internet.)
2. Create the remote boot image of the boot floppy using `flimage.exe`. The `flimage.exe` utility application is used to create a binary image of a 1.44-MB floppy disk. The floppy image is stored as 80 sequentially-numbered binary files starting with 0. Each file represents the contents of the corresponding cylinder from the floppy disk. You can find `flimage.exe` on the HP website (<http://www.hp.com/support>).
3. Place the boot image in a subfolder (for this example, `rboot` is the folder containing the boot image) under the folder where the TFTP server executable program resides. For example, if the TFTP server program `TFTP.exe` is in `C:\tftp`, then place the boot image in the folder `c:\tftp\rboot`.
4. Launch the executable file `TFTP.exe` and run TFTP.

Configuring virtual floppy from a Web browser

1. Log in to the remote management processor as described previously in the "Logging in to the remote management processor ("Logging in to LO100" on page 28)" section.
2. Click the **Virtual Floppy** link from the main menu navigation bar.
3. Enter the IP address of the TFTP server that you configured in the previous section.
4. Enter the path to the folder containing the floppy boot image. This path is relative to where the TFTP server program `TFTP.exe` resides. For example, if the TFTP server program `TFTP.exe` is in `C:\tftp` and the floppy boot image is in the folder `c:\tftp\rboot`, then the path would be `rboot`.

5. Click the **Apply** button.



Configuring the virtual floppy from the BIOS setup

1. On the target server, press the **F10** key during POST to enter BIOS setup.
2. In the BIOS Setup Utility, press the right arrow (→) key to navigate to the Advanced menu.
3. Press the down arrow (↓) key to scroll to IPMI. Press the **Enter** key.
4. Press the down arrow (↓) key to scroll to VSI configuration. Press the **Enter** key.
5. Select **Virtual Floppy**, and press the **Enter** key.
6. Select **Enabled**.
7. Press the down arrow (↓) key to scroll to TFTP Server IP Address, and enter the IP address of the TFTP server that you configured in the "Configuring the TFTP server (on page 39)" section of this guide.
8. Press the down arrow (↓) key to scroll to Floppy Timeout to change the default value.
9. Press the down arrow (↓) key to scroll to Image Directory Name. Press the **Enter** key.
10. In the Enter new Address Path box, enter the path to the folder containing the floppy boot image. This path is relative to where the TFTP server program, TFTP.exe, resides. For example, if TFTP.exe is in C:\tftp and the floppy boot image in C:\tftp\rboot, then the path would be rboot.
11. Press the **F10** key to save the changes and exit Setup.

Configuring virtual floppy from the CLP

1. Open a CLP window on the remote system, and enter `cd map1/nic1` at the command prompt.
2. Configure the TFTP server path by entering the following: `set oemhp_vsi_tftpserver=<path>` where <path> is the remote TFTP server IP address. For example:
`set oemhp_vsi_tftpserver=10.12.52.142`
3. Configure the VSI path by entering the following: `set oemhp_vsi_path=<path>`, where <path> the path to the folder containing the floppy boot image. This path is relative to where the TFTP server program TFTP.exe resides. For example, if the TFTP server program TFTP.exe is in C:\tftp and the floppy boot image in the folder c:\tftp\rboot, then the path would be rboot. For example:


```
set oemhp_vsi_path=rboot
```

4. Configure the remote file permission by entering the following: set oemhp_vsi_permission=<permission>, where <permission> is the file permission default RW (Read Write.) For example:
set oemhp_vsi_permission=rw

Rebooting the server

After the TFTP server and the virtual floppy are properly configured, the server can be rebooted using the remote floppy boot image that resides on the TFTP server. The methods for rebooting the server are described in "Controlling server power remotely (on page 30)." The server continues to reboot to the virtual floppy until the virtual floppy is disabled using the following procedure:

1. Ensure the target server is configured for network access. See "Network settings (on page 36)."
2. Press the **F10** key during POST to enter the BIOS Setup Utility.
3. Press the right arrow (→) key to navigate to the **Advanced** menu.
4. Press the down arrow (↓) key to scroll to **IPMI**. Press the **Enter** key.
5. Press the down arrow (↓) key to scroll to **VSI Configuration**. Press the **Enter** key.
6. Select **Virtual Floppy**, and press the **Enter** key.
7. Select **Enabled**.
8. Press the **F10** key to save and exit.

Platform event trap configuration

The PET Configuration screen enables you to set an alarm or specified condition originating on the server to alert an IPMI 2.0 supported systems management console. To access this page from a browser, click **PET Configuration** on the main menu navigation bar.

PET Destinations			
Destination	IP Address	MAC Address	
Alert1	0.0.0	00 00:00 00:00 00	Apply
Alert2	0.0.0	00 00:00 00:00 00	Apply
Alert3	0.0.0	00 00:00 00:00 00	Apply
Alert4	0.0.0	00 00:00 00:00 00	Apply
Alert5	0.0.0	00 00:00 00:00 00	Apply
Alert6	0.0.0	00 00:00 00:00 00	Apply
Alert7	0.0.0	00 00:00 00:00 00	Apply
Alert8	0.0.0	00 00:00 00:00 00	Apply

Alert Policy Table			
Entry	Policy Enable	Policy Number	Destination Selector
Entry1	Disabled	0	0
Entry2	Disabled	0	0
Entry3	Disabled	0	0
Entry4	Disabled	0	0

The PET Destinations section indicates where LO100 sends the PET (if configured.) This section has up to four entries specifying IP and MAC addresses. Enter either an IP address or a MAC address and click **Apply**. If both the a MAC and an IP address are entered, the IP address is used.

To set a policy, do the following:

1. Select the Policy Enable state and enter the Policy Number and Destination Selector information.
 - o The Policy Enable field enables you to selectively enable and disable trap forwarding.
 - o The Policy Number field enables you to select a policy that will be used in PEF configuration.
 - o The Destination Selector field specifies where to send the PET trap from the destinations defined in the PET Destination section.
2. Click **Apply**.

User administration

The User Configuration option on the main menu navigation bar enables you (if authorized) to edit the username and password for existing users. You must be logged in as a user with administrative privileges to modify the user configuration. You cannot create a new user. The user password is stored in nonvolatile memory and can be changed through a web browser ("[Changing user settings through a web browser](#)" on page 42) or the through the CLP ("[Changing user settings through the CLP](#)" on page 43).

When using CLP, if you do not have the correct privileges you are not prompted to log in with the correct credentials. You are warned if you have insufficient access. If you receive a warning message, you must end the telnet connection and re-establish a connection. There are no restrictions when logged in as administrator (admin). The second user always has the administrator privilege. User and operator accounts have the following access:

Option	User	Operator
Hardware Inventory	Yes	Yes
Virtual Power	No	Yes
Monitoring Sensors	View only	Yes
System Event Log	Yes	Yes
Network Settings	No	No
IPMI PET Configuration	No	No
User Configuration	No	No

Changing user settings through a web browser

The User Configuration screen displays user information and enables you to modify user settings. To access the User Configuration screen through a web browser, click **User Configuration** on the main menu navigation bar.

To modify user settings, do the following:

1. Click **User Configuration** on the main menu navigation bar.
2. Enter the password in the **Password** and **Confirm Password** fields.
3. Select the **User Privilege** level from the dropdown list. See "User administration (on page 42)" for more information on user privileges and access rights.
4. Change the user name if needed.
5. Click the **Set** button to save the changes.

Changing user settings through the CLP

1. Log in to the CLP as described in the "Logging in to LO100 (on page 28)" section.
2. At the command prompt, enter `cd map1/accounts`.
3. Select a user by entering `cd user1` or `cd user2`.
4. To change the user name, enter `set username=<new username>`. For example:
`./map1/accounts/user1/> set username=testuser1`
5. To change the user password, enter `set password=<new password>` and enter the new password when prompted. For example:
`./map1/accounts/user1/> set password=testpswd1`
Passwords are case-sensitive and can contain up to 16 characters.
6. To change the group name enter, `set group=<new group name>`. Valid group settings are `admin`, `user`, `OEM`, and `operator`. For example:
`./map1/accounts/user1/> set group=user`

Accessing the remote console through telnet

You can access the remote console through either the BIOS console text-redirection functionality or a Microsoft® Windows Server™ 2003 text-based console. Only one Remote Console window can be open at a time.

To start a remote console session, press the **Esc+Q** keys. To end a remote console session and return to the CLP press the **Esc+{** keys.

BIOS console text redirection through telnet

BIOS console text-redirection functionality enables you to view the entire boot process remotely and make changes in the BIOS Setup Utility from a remote computer. This tool is valuable in troubleshooting and managing servers remotely.

To configure the BIOS Setup Utility on the target system:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. Press the right arrow (→) key to navigate to the **Advanced** menu.
3. On ProLiant ML110 G3 servers:
 - a. Press the down arrow (↓) key to scroll down to the **BIOS Serial Console Configuration** option, and press **Enter**.
 - b. Verify the following settings:
 - BIOS Serial Console: Enabled
 - Serial Over LAN (SOL): Enabled
4. On ProLiant DL140 G2 and ProLiant DL145 G2 servers, press the down arrow (↓) key to scroll down to the **Console Redirection** option, and press the **Enter** key to access the submenu.
Verify the following settings:
 - Console Redirection: Enabled
 - Baud Rate: 9600
 - Terminal Type: VT100+

- Flow Control: None
 - Redirection After BIOS POST: On
5. On HP ProLiant ML150 G2 servers, press the down arrow (↓) key to scroll down to the Console Redirection option, and press the **Enter** key to access the submenu.
Verify the following settings:
 - Baud Rate: 9600
 - Console Type: VT100+
 - Flow Control: None
 - Continue C.R. after POST: On
 6. Press the **Esc** key to return to the previous screen.
 7. Scroll to the **I/O Device Configuration** option, and press the **Enter** key.
 8. On the ProLiant DL140 G2 and ProLiant DL145 G2 servers, verify that Serial Port is set to BMC COM PORT.
 9. Follow the instructions in the "Network settings (on page 36)" section to set or obtain a valid IP address.
 10. Press the **F10** key to save and exit.

After completing the console redirection process, view the boot process remotely from a client computer through an established telnet session to the IP address of LO100. See your operating system documentation for instructions on establishing telnet sessions.

When a telnet session is first established, an EMS> prompt appears. If the system is currently booting, the boot process is displayed. If you do not want to view boot, press the **Esc+(** keys. If the system is in the Operating System or off, the EMS> prompt appears, but disappears after pressing **Enter**.

To redirect the console to the telnet session and view the boot process, press the **Esc+Q** keys in the telnet session during server boot. If you reset the server using the telnet connection and press the **Esc+Q** keys, the boot process might not appear immediately. The boot process appears after the server resets. To end the session, press the **Esc+(** keys.

NOTE: If you encounter problems logging in to the remote console, be aware that some telnet programs might require you to enable their `send line feed at end of line` option. If the remote console does not respond to the Enter key, try setting this option in your telnet program.

NOTE: You must follow the instructions in the "Network settings (on page 36)" section to configure the network access properly.

Linux console redirection

In the remote console and servers with the Linux operating system, you can enable a remote login on ttyS0 by making the following changes to the BIOS Setup Utility and boot documents.

1. On the ProLiant DL140G2, ProLiant DL145G2, and ML150 G2 servers, verify or change the following:
Console Redirection:
Verify the following settings:
 - Baud Rate: 9600

- Console Type: VT100+
- Flow Control: None
- Continue C.R. after POST: On
- Serial Port: BMC COM PORT (on the ProLiant DL140 G2 and ProLiant DL145 G2 servers only)

NOTE: To customize the examples for your server, do the following:

- On DL140 G2 servers, replace ttyS0 with ttyS3
 - On DL145 G2 servers, replace ttyS0 with ttyS2
-

2. In the `/boot/grub/menu.lst` file, append the following to the kernel startup instruction:


```
console=ttyS0 115200
```

 Comment out the line `GRAPHICAL DISPLAY LINE`

```
# splashimage=(hd0,0)/grub/splash.xpm.gz
```
3. Add an entry to allow serial console login in `/etc/inittab`. For example:


```
S0:12345:respawn:/sbin/agetty -L 115200 ttyS0 vt102
```
4. In `/etc/securetty` enable root access to ttyS0 by adding the `ttyS0`.
5. In `/etc/sysconfig/kudzu`, set kudzu to not perform serial port probing during boot. For example:


```
SAFE=yes
```
6. After modifying and saving the following files, reboot the server. You can now log in to the operating system through remote console.

After POST, in the remote console, the server prompts you with a login. Enter a valid login and use the server as you normally would. Use the `ESC+Q` keys to start remote console through the telnet and the `ESC+(` keys to exit the remote console in telnet.

Microsoft Windows® EMS management

Microsoft® Windows Server™ 2003 provides text-based console access. You can connect a laptop to the LO100 to perform basic management tasks on the target system. The Windows® EMS Console, if enabled, displays the processes that are running and enables administrators to halt processes. This capability is important in cases where video, device drivers, or other operating system features have prevented normal operation and normal corrective actions.

To enable Windows® EMS management on the target system:

1. Press the **F10** key during POST to enter the BIOS Setup Utility.
2. On ProLiant ML110 G3 servers:
 - a. Press the down arrow (↓) key to scroll down to the BIOS Serial Console Configuration option, and press **Enter**.
 - b. Verify the following settings:
 - BIOS Serial Console: Enabled
 - Serial Over LAN (SOL): Enabled
3. On ProLiant 140 G2, ProLiant DL145 G2, and ProLiant ML150 G2 servers, press the right arrow (→) key to scroll down to **Advanced>Console Redirection** menu.
 - a. Press the down arrow (↓) key to scroll down to **EMS Console** option, and press the **Enter** key to access the submenu.
 - b. Verify the following settings:

- Console Redirection: Enabled
 - Baud Rate: 9600
 - Terminal Type: VT100+
 - Flow Control: None
 - Redirection After BIOS POST: On
4. Press the **Esc** key to return to the previous screen, or press the **F10** key to save the changes and exit Setup.

After enabling Windows® EMS management, you can view the Windows® EMS management console remotely from a client computer through an established telnet session to the IP address of the target server by pressing the **Esc+Q** keys. To end an EMS session press the **Esc+(** keys. See your operating system documentation for instructions on establishing telnet sessions.

NOTE: If you encounter problems logging in to the remote console, be aware that some telnet programs might require you to enable their `send line feed at end of line` option. If the remote console does not respond to the Enter key, try setting this option in your telnet program.

HP SIM support

HP SIM discovers LO100 and enables you to identify and launch LO100. See your HP SIM user guide for more information on using HP SIM with LO100.

Acronyms and abbreviations

BIOS

Basic Input/Output System

BMC

baseboard management controller

CLI

Command Line Interface

CLP

command line protocol

DHCP

Dynamic Host Configuration Protocol

DSA

Digital Signature Algorithm

EMS

Emergency Management Services

HP SIM

HP Systems Insight Manager

HTTP

hypertext transfer protocol

IP

Internet Protocol

IPMI

Intelligent Platform Management Interface

JVM

Java Virtual Machine

KCS

Keyboard Controller Style

KVM

keyboard, video, and mouse

LO100

HP Lights-Out 100 Remote Management processors

MAC

medium access control

NIC

network interface controller

OS

operating system

PEF

Platform Event Filtering

PEM

Privacy Enhanced Mail

PET

Platform Event Trap

POST

Power-On Self Test

RBSU

ROM-Based Setup Utility

SLES

SUSE LINUX Enterprise Server

SMASH

System Management Architecture for Server Hardware

SSH

Secure Shell

SSL

Secure Sockets Layer

TCP/IP

Transmission Control Protocol/Internet Protocol

TFTP

Trivial File Transfer Protocol

URL

uniform resource locator

VNC

virtual network computing

Index

A

- access options 28
- accessing software, browser 28
- administration 11
- alert messages 41

B

- base management controller (BMC) 11
- Basic Input/Output System (BIOS) 16, 32
- BIOS (Basic Input/Output System) 16, 32
- BIOS console, text redirection 43
- BIOS upgrade 16
- BMC (base management controller) 11
- browser-based setup 36

C

- certificates, generating 21
- certificates, installing 21
- CLP (Command Line Protocol) 5, 11, 14, 16, 21, 22, 23, 27, 28, 29, 30, 31, 34, 35, 36, 38, 40, 42, 43
- CLP overview 22
- CLP, base commands 23
- CLP, commands 31, 35, 36, 40, 43
- CLP, connection options 22
- CLP, general syntax 22, 23
- CLP, specific commands 27
- CLP, using 22
- Command Line Protocol (CLP) 5, 11, 14, 16, 21, 22, 23, 27, 28, 29, 30, 31, 34, 35, 36, 38, 40, 42, 43
- configuration procedures 11
- configuration, network 11, 36
- configuring the LOM processor 11
- connectors, illustrated 8, 9
- console redirection 13
- console redirection, Linux 44

D

- data protection methods 19
- dedicated management port 13

- DHCP (Dynamic Host Configuration Protocol) 11, 14, 15, 28, 36, 37
- DHCP addresses 14
- DHCP, disabling 15
- DHCP, enabling 14
- Dynamic Host Configuration Protocol (DHCP) 11, 14, 15, 28, 36, 37, 47

E

- Emergency Management Services (EMS) 45
- EMS (Emergency Management Services) 45
- EMS Console 45
- encryption 19, 20
- Ethernet connections 14
- event log 34
- event log entries 34
- event log, BIOS setup access 35
- event log, browser access 34
- event log, CLP access 35

F

- features, CLP 22
- features, IPMI 2.0 27
- features, overview 5
- features, SSL 19
- firmware, updating 16
- flash ROM 16

H

- hardware inventory 30
- HP Systems Insight Manager, support 46
- HTTP (hypertext transfer protocol) 11, 12, 15, 19
- hypertext transfer protocol (HTTP) 11, 12, 15, 19

I

- importing 21
- installation instructions 7, 9
- installation requirements 7
- installation, management card 7, 9
- installing management card 8, 9
- Intelligent Platform Management Interface (IPMI) 5, 11, 27, 29, 33, 34, 40, 41, 42

Internet Protocol (IP) 11
IP (Internet Protocol) 11
IP address assignment 15
IPMI (Intelligent Platform Management Interface) 5,
11, 27, 29, 33, 34, 40, 41, 42
IPMI support 27

K

key, public 21
kit contents 7

L

Linux, console redirection 44
LO100 settings 19
LO100, logging in through browser 28
LO100, remote management 19
LO100c connectors 8, 9
logging in 28, 29
logging in, through a browser 28
logging in, through the CLP 29

M

main menu functions 29
management card, installing 8, 9
medium access control (MAC) 41
monitoring sensors 32

N

network access 11
network access, configuring 11
network interface controller (NIC) 5, 7, 12, 13, 36,
40, 48
network settings 11, 36
network settings, configuring through the BIOS
setup 37
network settings, configuring through the CLP 36
NIC (network interface controller) 5, 7, 12, 13, 36,
40

O

operational overview 5
overview, CLP 22
overview, server management 5
overview, SSH 20
overview, SSL 19

P

password, changing through a browser 42
password, changing through the CLP 43
passwords 42
PEF entires, 33
Platform Event Filtering (PEF) 33, 41
POST (Power-On Self Test) 9, 11
post-installation procedures 9
power control options 31
power cycle server 30
powering on/off 30, 31, 32
Power-On Self Test (POST) 9, 11
preinstallation, guidelines 7
privileges, user 42
processors 30
public key 21

R

RBSU (ROM-Based Setup Utility) 34
reboot, server 41
remote console, using 43
remote management card connectors 8, 9
remote management processor, logging in through
CLP 29
remote management, browser main menu 29
remote server power, controlling 31, 32
requirements, SSH 20
ROM-Based Setup Utility (RBSU) 34
ROMPaq utility 16

S

safety considerations 7
Secure Shell (SSH) 20, 21, 22, 29
Secure Sockets Layer (SSL) 21
sensor data, BIOS access 32
sensor data, browser access 32
sensor data, viewing 32
serial port 12
serial port, BIOS console configuration 13
serial port, enabling 12
server management 5
settings, network 36
settings, PEF 33
settings, power options 31
side-band connection 14
SMASH (System Management Architecture for Server
Hardware) 5, 22
SSH (Secure Shell) 20, 21, 22, 29
SSL, (Secure Sockets Layer) 21

- SSL, importing key and certificate 21
- SSL, overview 19
- SSL, using 19
- static IP addresses 15
- support, HP Systems Insight Manager 46
- support, IPMI 27
- system event log, access through the BIOS 35
- system event log, access through the CLP 35
- system event log, using 34
- System Management Architecture for Server Hardware (SMASH) 5, 22

T

- telnet 15, 43
- TFTP (Trivial File Transfer Protocol) 16, 17, 21, 23, 38, 39, 40, 41
- TFTP, configuration 17, 39
- Trivial File Transfer Protocol (TFTP) 16, 17, 21, 23, 38, 39, 40, 41

U

- UID (unit identification) 5, 22
- unit identification (UID) 5, 22
- user access 11, 42
- user account, modifying 11, 42
- user and configuration settings 11, 42
- user guide updates 5

V

- virtual devices 38
- virtual floppy, configuring from BIOS setup 40
- virtual power 30
- virtual storage interface (VSI) 13, 39, 40, 41
- VSI (virtual storage interface) 13, 39, 40, 41

W

- Windows® EMS Console, enabling 45

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>