

DST Setting Module : 5441

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode from any other mode, hold down (D) button for about two seconds.

1.  ADJ



Hold down (A) button until ADJ appears in the upper display.

2.  City Code



When you release the button, City Code will be flashing in the upper display.

3. 

Press (D) button once.

4.



DST indicator and OFF/ON.

DST indicator and the DST setting (ON or OFF) will appear in the upper display .

5.



Press (E) button to toggle ON and OFF.

6.



Press (A) button to exit the setting screen.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>