


Control Units for Pharo® Shower Temples® and Shower Panels®

Semielectronic Steam Version (K4 Sensotronic Steam)



Shower Temple 115 Deluxe DL 40

- 1 Light button on/off
- 2 LCD display
- 3 Buttons +/- for: cascade, steam timing, steam output, light programme*/-timing*
- 4 Cursor button
- 5 Overhead shower
- 6 Body shower
- 7 Cascade function
- 8 Hand shower
- 9 Steam on/off
- 10 Valve for cascade shower
- 11 Scald protection: for temperatures above 38° C press button and turn knob
- 12 Thermostatic mixer 1/2"

Features:

- Thermostatic mixer with scald protection and separat valve for cascade shower
- Control unit for shower operation, steam-, lightcontrol
- Adjustable steam output (up to 60 minutes) and intensity (30-100 %)
- LCD display indicates:
 - water temperature
 - desired timing of cascade function
 - steam output in minutes
 - desired steam output in %
 - cabin temperature
- Illuminated symbols at the display


Products:

- Shower Temple DL 40 DeLuxe
- Shower Temple ST 40 Steam

*Light/-programme/-timing:

- Standard for Shower Temple DL 40 DeLuxe
- Option for Shower Temple ST 40 Steam

Electronic version (K4 Electronic)



Shower Panel Prestige EL 40

- 1 Light button
- 2 Scald protection; for temperatures above 42° C press button
- 3 LCD display
- 4 Temperature control +/-
- 5 Timing for cascade function +/-
- 6 Cursor button for the selection of programme parts
- 6 Overhead shower
- 7 Body shower
- 8 Cascade funktions
- 9 Hand shower

Features:


- Electronic controlled thermostatic mixer with scald protection
- Electronic controlled shower operation
- Self-diagnosis
- Illuminated symbols
- LCD display indicates:
 - water temperature
 - desired timing of cascade function
 - error messages

Products:

- Shower Panel Prestige EL 40

Control Units for Pharo® Shower Temples® and Shower Panels®

Semielectronic (K4 Sensotronic)



Shower Panel Prestige SL 20

- ① Light button
- ② LCD display
- ③ Timing for cascade function +/-
- ④ Overhead shower
- ⑤ Body shower
- ⑥ Cascade function
- ⑦ Hand shower
- ⑧ Scald protection: for temperatures above 38° press button and turn knob
- ⑨ Thermostatic Mixer 1/2"


Features:

- Thermostatic mixer with scald protection
- Electronic controlled shower operation
- Illuminated symbols
- LCD display indicates:
 - water temperature
 - desired timing of cascade funktion

Products:

- Shower Panel Prestige SL 20
- Shower Temple SL 40 Sensotronic

Manual (MTC Ecostat with additional stop valve)



Shower Temple 90 Quadra ML 40

- ① Stop-/diverter valve for overhead- and body shower
- ② Extra valve for hand shower
- ③ Scald protection: for temperatures above 38° press button and turn knob
- ④ Thermostatic mixer 1/2"

Features:


- Thermostatic mixer with scald protection
- Stop-/diverter valve for control and operation of over head- and body showers
- Separate stop valve for the operation of the hand shower
- Adjustable flow rate
- Combination of two showers possible
- Maximal two showers may be inter-connected

Products:

- Shower Temple Quadra ML/M 40

Control Units for Pharo® Shower Temples® and Shower Panels®

Manual (MTC Ecostat)



Shower Panel Moonlight M 20

- 1 Stop-/diverter valve for hand- and body shower
- 2 Scald protection: for temperatures above 38° press button and turn knob
- 3 Thermostatic mixer 1/2"

Features:

- Thermostatic mixer with scald protection
- Stop-/diverter valve for control and operation of overhead- and body showers
- Adjustable flow rate
- Combination of two showers possible

Products:

- Shower Panel Moonlight ML/M 20
- Shower Column with hand shower
- Shower column with overhead shower

Manual (Variotherm 50)



- 1 Scald protection: for temperatures above 38° press button and turn knob
- 2 Thermostatic mixer 1/2"
- 3 Stop-/diverter valve for overhead-, hand- and body shower

Features:


- Thermostatic mixer with scald protection
- Stop-/diverter valve for control and operation of overhead- and body showers
- Adjustable flow rate
- Combination of two showers possible

Products:

- Shower Temple ML 40 Manual

Control Units for Pharo® Shower Temples® and Shower Panels®

Manual (Quattrostat)



Shower Panel Prestige ML 20

- ① Scald protection: for temperatures above 38° press button and turn knob
- ② Thermostatic mixer 1/2"
- ③ Body shower
- ④ Overhead shower
- ⑤ Hand shower
- ⑥ Stop-/diverter valve


Features:

- Thermostatic mixer with scald protection
- Stop-/diverter valve
- Adjustable flow rate
- Combination of two showers possible

Products:

- Shower Panel Helis ML 20
- Shower Panel Prestige ML/M 20
- Shower Panel Lift M 20

Manual (Triostat Plus)



Shower Panel Comfort Plus (Thermostat Version)

- ① MTC Thermostatic mixer 1/2"
- ② Scald protection: for temperatures above 38° press button and turn knob
- ③ Stop-/diverter valve

Features:

- Thermostatic mixer with scald protection
- Stop-/diverter valve
- Adjustable flow rate
- Combination of two showers possible

Products:

- Shower Panel Comfort Plus M 20 (Triostat Plus Version)
- Shower Panel Comfort Plus M 20 (for bathtub)

Control Units for Pharo® Shower Temples® and Shower Panels®

Manual (single lever mixer with diverter)



- ① Diverter to activate the body showers
- ② Single lever mixer

Features:

- Single lever mixer with ceramic discs
- Pullknob to switch from hand- to body shower
- Reverts automatically from shower to bath function
- Possible to switch between shower functions while in operation
- Adjustable flow rate

Products:

- Shower Panel Comfort Plus M 20 (with single lever mixer)

Operational Functions

	K4 Sensotronic Steam	K4 Electronic	K4 Sensotronic	Manual: MTC (stop valve)	Manual: MTC	Manual: Quattrostat Klick	Manual: Quattrostat	Manual: Triostat	Manual: Single lever mixer
Shower Temple									
100/115 Deluxe DL 40	●	-	-	-	-	-	-	-	-
100/115 Steam ST 40	●	-	-	-	-	-	-	-	-
90/100/115 Senso. SL 40	-	-	●	-	-	-	-	-	-
90/100/115 Manual ML 40	-	-	-	●	-	●	-	-	-
90/100 Quadra ML/M 40	-	-	-	●	-	-	-	-	-
Shower Panel									
Helis ML 20	-	-	-	-	-	-	●	-	-
Moonlight ML/M 20	-	-	-	-	●	-	-	-	-
Prestige EL 40	-	●	-	-	-	-	-	-	-
Prestige SL 20	-	-	●	-	-	-	-	-	-
Prestige ML/M 20	-	-	-	-	-	-	●	-	-
Lift M 20	-	-	-	-	-	-	●	-	-
Lift 2 M 20	-	-	-	-	-	●	-	-	-
Comfort Plus (for bathtub)	-	-	-	-	-	-	-	●	-
Comfort Plus (with thermostat)	-	-	-	-	-	-	-	●	-
Comfort Plus (with mixer)	-	-	-	-	-	-	-	-	●
Shower column									
			-		●				

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>