

# Model Quatech USBN-500NAS

2-Port USB 2.0 Device and  
2-Port NAS Device Server over IP

## Quick Installation Guide

- The default IP of this USB device server is 192.168.3.22:901
- If you need to change IP of this device server, please set up your PC as 192.168.3.XXX where XXX is a different number from 22.
- After set up your PC IP, then open a web page, and type <http://192.168.3.22:901> to reach the Logon page. Username is “root”, and password is “combo”.
- For more detailed setup & functions of this device server, please refer to User’s Manual.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>