

Dual Band sect-xxxx GPRS Telephone Quick Reference Card

Answer a Call	Open the phone or Press the key.	Save Numbers in Phonebook	<ol style="list-style-type: none"> 1. Enter the number. 2. Press the Save soft key. 3. Select an icon for label. 4. Press the Select soft key. 5. Enter the name. 6. Press the OK soft key. 7. If necessary, change the memory. 8. Press the key to return to Standmode.
Adjust the Volume	Press the or key on the left side of the phone.	Search for a Number in Phonebook	<ol style="list-style-type: none"> 1. Press the Search soft key. 2. Select the Search option. 3. Enter the first few letters of the name. 4. To scroll through the names, press the Up or Down key. 5. Press the View soft key. 6. To scroll through the numbers, press the Up or Down key. 7. Press the key to dial.
Choose the Alert Type	<ol style="list-style-type: none"> 1. Select the Alert Type menu option (Menu 3.3). 2. Select an option: <ul style="list-style-type: none"> • Light Only • Melody • Vibration • Vibrate+Melody 3. Press the Select soft key. 		
Scrolling the Microphone Off/on During a Call	<ol style="list-style-type: none"> 1. Press the Options soft key. 2. Highlight Mute or Unmute. 3. Press the Select soft key. 		

Press and hold the key.	<ol style="list-style-type: none"> 1. Key in the number. 2. Press the key. 	
Switch On/Off	<ol style="list-style-type: none"> 1. Press the key. 	
Make a Call	<ol style="list-style-type: none"> 1. Key in the number. 2. Press the key. 	
End a Call	<ol style="list-style-type: none"> 1. Press the key. 	
View Missed Calls Immediately After Missing Them	<ol style="list-style-type: none"> 1. Open the phone and press the View soft key. 2. Scroll with the Up and Down keys through the missed calls. 3. To return the call, press the key. 	

Access the Menu Functions	<ol style="list-style-type: none"> 1. Press the Menu soft key. 2. Scroll with the Up and Down keys through the list of the menus until you reach the required menu. 3. Press the Select soft key. 4. Scroll with the Up and Down keys through the list of the options until the required one is selected. 5. Press the Select soft key.
----------------------------------	--

Each of the two soft keys and perform the function indicated by the text above it, on the bottom line of the display.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>