



5000 Watt Portable Generator Illustrated Parts List




This generator is rated and certified to be compliant with CSA (Canadian Standards Association) standard C22.2 No. 100-04 (motors and generators).

BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

030380 Manual No. 206590A Revision - (03/11/2008)

Exploded Views and Parts Lists

EXPLODED VIEW - MAIN UNIT



Copyright © 2008 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

Exploded Views and Parts Lists

PARTS LIST - MAIN UNIT

Item	Part #	Description	Item	Part #	Description
1	206822GS	ASSY, Cradle (Includes #'s 20, 31 & 53)	40	199433GS	KIT, Fuel Tank Hardware w/U-Clips
2	194150GS	KIT, Vibration, Mount, 45°		199284GS	U-CLIPS, (Optional Accessory)
3	67989GS	NUT, M8 Flange Serrated	41	192980GS	KIT, Valve, Fuel Tank
4	190220GS	HOUSING, Engine Adapter	42	*	WASHER, M6 Lock
5	NSP	ASSY, Alt (see page 4)	43	691656	SOLENOID
6	*	NUT, Hex M8 - 1.25	44	200814GS	ASSY., Tank, Fuel (Includes items 41, 50, 51, 52, 54 & 55)
7	*	TPHMS, M8 - 1.25 x 35	45	B4363GS	CAP, Fuel Gauge
8	96796GS	WASHER, 8.4 x 22.2 x 3	47	*	NUT, Hex, M6 - 1.0
9	198611GS	PPHS, 1/4-20 x .05 Trilobular	48	195373GS	WIRE, Ground
10	190274BGS	SBHCS, 3/8 - 16 x 1	49	185931KGS	WIRE
11	47480GS	HHCS, 5/16-24 x 7	50	188333GS	DECAL, Gas Fill
12	*	HHCS, M8 - 1.25 x 25	51	194984GS	DECAL, Danger
13	198763GS	KIT, Handle	52	94480GS	DECAL, Start Instructions
14	189009GS	BRACKET, Muffler	53	200311GS	DECAL, Neutral Bonded
15	695398	GASKET, Exhaust	54	202997GS	DECAL, CO Warning
16	*	HHCS, M6 - 1.0 x 12 w/LW	55	197798GS	DECAL, Shut-Off, Fuel
17	189008GS	MUFFLER	58	201575GS	ASSY, Control Panel
18	*	SHCS, M8 - 1.25 x 20	59	*	NUT, Palnut, 3/16"
19	83083GS	SCREEN, Spark Arrest	60	198871EGS	WIRE
20	B4986GS	DECAL, Ground, Green	68	199150GS	KIT, Battery Cover w/Insulation
21	194153GS	KIT, Vibration Mount	69	198711GS	BATTERY
22	86494GS	SCREW, Wing M6 - 1.0 x 16	70	87799GS	SWITCH, Rocker
23	B2153GS	SCREW, 12 - 14 x 7/8, Self Drill	71	198925GS	ASSY, Jack Coaxial
24	197424GS	SHIELD, Heat	72	198871LGS	WIRE
25	191190GS	CAP	73	198871KGS	WIRE
26	74908GS	SCREW, M5-0.8 x 10, Taptite	76	185931LGS	WIRE, Battery Negative
27	199228GS	INSULATION	78	185931JGS	WIRE, Battery Positive
28	198700GS	KIT, Battery Tray w/Insulation	900	§	ENGINE
29	199156GS	INSULATION			
30	199157GS	INSULATION			
31	200310GS	DECAL, Exhaust Warning			
32	*	WASHER, Lock 5/16 - M8			
33	187117GS	STUD, Double			
34	195422GS	COVER, RBC, Plastic with Cap			
35	791745	KIT, Fuel Hose, w/Clamps			
36	*	WASHER, Lock, 1/4			
37	56893GS	CRIMPTITE, 10-24 x 1/2			
38	*	NUT, 1/4-20			
39	*	WASHER, Shakeproof, Ext. M6 1/4			

Parts Not Illustrated


206590GS	MANUAL, Operator's
B4177GS	CHARGER, Battery
BB3061BGS	OIL BOTTLE
206818GS	KIT, Decals, Service

§ - Contact Engine Manufacturer

* - Items without part numbers are common fasteners and are available at your local hardware store.


Exploded Views and Parts Lists

ALTERNATOR EXPLODED VIEW & PARTS LIST



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	204105GS	ASSY., Rotor (Includes Item 8)
3	203936GS	STATOR
4	186060GS	RBC, with O-Ring (p/n 189197)
5	86308CGS	HHCS, M6 - 1.0 x 130 SEMS
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	65791GS	BEARING
9	91551GS	PIN, Groove

CONTROL PANEL EXPLODED VIEW & PARTS LIST




Item	Part #	Description
1	201571GS	PANEL, Control
2	197472GS	COVER, Outlet Flip
3	201572GS	COVER, Back Panel
4	197731GS	OUTLET, 120V, 15/20A Duplex
5	189164GS	NUT, 3/16 Pal
6	202951GS	MODULE, Led
7	*	SCREW, 3 x 6, Tapping
8	202030GS	BREAKER, Circuit, 20A
	191481GS	BOOT, Breaker Circuit (not shown)
9	43437GS	OUTLET, 120/240V, 30A
10	201678GS	HOUSING, Receptacle, 6 Pin
11	*	PPHS, M3 - 0.5 x 12

* - Items without part numbers are common fasteners and are available at your local hardware store.

Exploded Views and Parts Lists

WHEEL KIT EXPLODED VIEW & PARTS LIST



Item	Part #	Description
1	196517GS	WHEEL
2	B1764GS	SUPPORT, Wheel Kit
3	191267HGS	AXLE
4	*	WASHER, 5/8"
5	191265GS	E-RING
6	67989GS	NUT, M8 - Flange Serrated
7	*	HHCS, M8 - 1.25 x 16

Parts Not Illustrated

197594GS SUBKIT, Hardware

* - Items without part numbers are common fasteners and are available at your local hardware store.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>