harman/kardon[®]





Safety Instructions

Headphone/earphone listening at high volume levels may cause permanent damage to your hearing. Always set the volume control to the lowest level before switching to different sources (tuner, CD player, MPs player, etc.) or before plugging in the headphones/earphones. For your safety, do not use headphones/earphones while driving or cycling.

Earphone Removal

- · To avoid discomfort, use a slow twisting motion to gradually break the seal.
- · Open the jaw slightly to equalize pressure, because suction can occur when the eartip is removed.

Headphone Regulatory Requirements

U.S., Europe (+TUV), UK, Japan, China, Singapore, Taiwan, Mexico, Korea, Australia, New Zealand

Headphone Language Requirements

English, French, Spanish, German, Korean, Chinese, Japanese, Norwegian, Dutch, Danish, Italian

Welcome

Thank you for purchasing the Harman Kardon® EP 730 noise-isolation earphone system. This system has been designed to meet Harman Kardon's highest audio-performance standards. The Harman Kardon EP 730 will meet all your listening and travel needs, and enable you to immerse yourself in your favorite music, wherever you are.

Introduction

Acoustically advanced Harman Kardon 700 Series earphones deliver clear, accurate sound from any portable music or DVD player. Their lightweight, in-ear design blocks out ambient noise better than many bulky battery-powered sound-canceling headphones. You can enjoy the full dynamic range of your favorite music and movies without cranking up the volume to unnatural – or even unsafe-listening levels.

Package Contents


- 1. EP 730 Earphones
- 2. Flange ear tips (one pair)
- 3. Foam eartips (one pair)
- 4. Replacement filters 1 pair
- s. Filter-changing tool
- 6. Carrying case
- 7. Bass Boost/Volume control



2


Download from Www.Somanuals.com. All Manuals Search And Download.

Dimensional Layout




Bass Boost/Volume Control

hoost- No VC



HF – High Fidelity Most accurate response + VC

Construction



- Snirt clip
- 3. Bass Boost / Volume control
- 4. Earphone

Technical Specification

Manufacturer: Harman Consumer Group, Inc. Model: EP 730

Available in: Black or White

Input Requirement: Main connection – 3.5mm mini stereo jack
Max Power Input: 45 mW (HF mode)/16 mW (B mode)

Dimensions: Wire length – 150cm

Compatibility: All audio output devices with a 3,5mm or stereo phono audio jack Sensitivity (@ 1kHz): 95dB SPL (max VC) for a 0.1V RMS input in HF position 10xdB SPL (fixed) for a 0.1V RMS input in B position

Impedance: 48 Ohms (HF mode); 16 ohms (B)

Noise Isolation: 35 dB (three-flange ear tip deeply seated)

40 dB (foam ear tip deeply seated)

40 dB (foam ear tip deeply seated)

Frequency Response: 20 Hz – 15 kHz

Weight: 20.0 Grams (1.5m cable included)

Proper Care

- · Do not expose earphones to extreme temperatures.
- · Avoid dropping or strong impact. Extreme shock can damage the earphones.
- · Always leave an eartip on the earphone for shock protection.
- Perspiration entering the nozzle may cause the earphone to temporarily stop working. Normal operation usually resumes after the earphone dries out.
- · Do not pull on the cord to remove it from the jack or the ear.
- · Clean or replace the ear tips prior to use and following by others.
- · Replace disposable foam ear tips regularly.
- · Earwax buildup can reduce the earphone output. When the filters become clogged, they should be replaced. See Changing Filters.

Caution

Consult a physician or audiologist if you have excessive cerumen, difficulty inserting the eartips, or discomfort after prolonged use. It is unsafe to use interest earphones with deriving a motorized whelice, operating machinery, bicyting or jogging, because you may not be alerted to potential danger. Do not use the earphones at excessively loud levels. Noise-induced hearing loss is a result of exposure time, the average sound level and the peach of very loud sounds. Decreased listening levels allow for longer periods of safe listening time.

Changing Filters



1. Remove eartip



Firmly push the sharp tip of the filter tool into the center of the filter.



Pull out the entire filter and plastic ring.

Filter Replacement



1. With your integers, but the natrow end of a new filter into the end of the earphone. Be careful to put the open end in first so that the filter can be seen at the tip of the earphone. Gently push on the filter and snap it into the earphone. You should feel and hear it snap in place.



Add the eartip back onto the earphone.

H A Harman International Company
Harman Consumer Group, Inc.
8500 Balboa Boulevard, Northridge, CA 91329 USA
1 518 255 4545

www.ibl.com

Made in China. Fabriqué en Chine.

© 2006 Harman International Industries, Incorporated. All rights reserved. Tous droits réservés.

Harman Kardon and Harman International are trademarks of Harman International Industries, Incorporated, registered in the United States and/or other countries.

Harman Kardon et Harman International sont des marques commerciales de Harman International Industries Incorporated, déposées aux États-Unis et/ou dans d'autres pays.

Harman Kardon's model 730 earphones, are covered by necessary for design patents no. 452313-6002, and other patents pending. errolone Reseases. Document Number: 8x0-0167-001

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com