

HZ432

HEAT 1	<input type="checkbox"/>	ZONE 1
HEAT 2	<input type="checkbox"/>	
HEAT 3	<input type="checkbox"/>	ZONE 2
COOL 1	<input type="checkbox"/>	
COOL 2	<input type="checkbox"/>	ZONE 3
PURGE	<input type="checkbox"/>	
FAN	<input type="checkbox"/>	ZONE 4
EM HEAT	<input type="checkbox"/>	

EMERGENCY  
HEAT

**Honeywell**

# TrueZONE™ (HZ432) Panel

## Zoning Made Effortless

Using our more than 50 years experience in the zoning business combined with feedback from hundreds of contractors like you, together we've developed a new family of zoning panels that make zoning truly effortless. Introducing TrueZONE™ — the next generation of zoning panels from Honeywell.


If you've ever installed a zoning system by setting manual dip switches, you'll appreciate the simplicity, convenience and time savings that TrueZONE offers. TrueZONE helps eliminate callbacks by ensuring that the system is operating properly before the installer leaves the job site. It all adds up to true comfort for your customers and true profit for your bottom line.

### TrueZONE™ features include:

- 1. Intuitive Installer Setup** – Easy-to-follow, digital display uses real language to guide installer through four simple steps for system setup:
  1. Select Equipment Type (Conventional, Heat Pump or Dual Fuel)
  2. Select Heat/Cool Stages (up to 3H/2C)
  3. Select Number of Zones (2-32)
  4. Select Stage Control (Thermostat, Timer, % of Zones)
- 2. Standardized Checkout Procedure** – Standardizes the checkout process so that every installer checks out in the same way, every time and helps ensure that all zones are operating correctly before leaving the job site. Only one installer needed for checkout.
- 3. Robust Push Terminals** – Push-in terminal blocks wire in literally half the time compared to screw terminals – with no screwdriver required. Plus, wires lock-in to the terminals for a tight fit.
- 4. Common-Sense LEDs** – Indicate which zones are calling, what stage they are calling for (heat/cool) and when the emergency heat is on.
- 5. Universal Application** – Works with virtually any brand equipment for zone control of conventional, heat pump or dual fuel systems up to 3H/2C.
- 6. Clean, Professional Installation** – Wire channel allows installer to run wires on the side, top, bottom or backside of the panel and wire anchors help hold wires in place.
- 7. Smaller Footprint** – Gives installer the ability to mount TrueZONE panels anywhere – on the return duct, studs or wall next to the system. All panels are 8 inches wide.
- 8. Variable-Speed Fan Control** – Reduces blower speed in cooling when one zone is calling.
- 9. Discharge Temperature (DATS) Staging** – Downstages equipment when discharge air temperature is near the limit.
- 10. Advanced Dual-Fuel Operation** – Offers dual-fuel changeover based on outdoor temperature and/or thermostat staging.

**Exclusive Zoning Support** – Honeywell backs your zoning efforts with a 5-year warranty, a dedicated toll-free Zoning hotline (1-800-TAT-TEMP), local zoning specialists, training, free literature, Contractor PRO™ rewards and more.

**Take Your Zoning Business to the Next Level** – Make more money by reducing labor and call back costs by making TrueZONE panels your new standard.



**ZONE 4**  
 M1 common  
 M4 open  
 M6 closed

**THERMOSTAT**  
 R  
 C  
 W1/E  
 W2  
 W3  
 Y1  
 Y2  
 G  
 O/B  
 L

**EQUIPMENT**  
 RH  
 RC  
 W1/E  
 W2  
 W3  
 Y1  
 Y2  
 G  
 O  
 B  
 DS/BK

**POWER**  
 R  
 C

**ACCESSORIES**  
 AZ1  
 AZ2

**SENSOR**  
 OT  
 OT  
 DATS  
 DATS

**HZ432**

HEAT 1  ZONE 1  
 HEAT 2   
 HEAT 3   
 COOL 1  ZONE 2  
 COOL 2   
 PURGE   
 FAN  ZONE 3  
 EM HEAT  ZONE 4

EMERGENCY HEAT

**ZONE 1**  
 M1 common  
 M4 open  
 M6 closed

**THERMOSTAT**  
 R  
 C  
 W1/E  
 W2  
 W3  
 Y1  
 Y2  
 G  
 O/B  
 L

**ZONE 2**  
 M1 common  
 M4 open  
 M6 closed

**THERMOSTAT**  
 R  
 C  
 W1/E  
 W2  
 W3  
 Y1  
 Y2  
 G  
 O/B  
 L

**ZONE 3**  
 M1 common  
 M4 open  
 M6 closed

**THERMOSTAT**  
 R  
 C  
 W1/E  
 W2  
 W3  
 Y1  
 Y2  
 G  
 O/B  
 L

HOME  **2**  
 CONFIG   
 CHECK OUT  MODE

**1** SYSTEM TYPE  
 (CONV) HEATPUMP

BACK ADJUST SETTING NEXT

**10**

## TrueZONE™ Panels

Part Number	Description
HZ432	Four zone, 3H/2C panel used for conventional, heat pump or dual fuel systems
HZ322	Three zone, 2H/2C panel used for conventional or heat pump equipment
HZ311	Three zone, 1H/1C panel used for conventional equipment
HZ432K	Includes (1) HZ432 Panel, (1) Transformer and (1) C7735A discharge air temperature sensor
HZ322K	Includes (1) HZ322 Panel, (1) Transformer and (1) C7735A discharge air temperature sensor
HZ311K	Includes (1) HZ311 Panel, (1) Transformer and (1) C7735A discharge air temperature sensor

## Thermostats

Part Number	Description
YTH9421C1002	VisionPRO® IAQ Programmable Thermostat with Equipment Interface Module
TH8321U1006	VisionPRO® 7-Day Touchscreen Programmable 3H/2C with Dehumidification Control
TH8320U1008	VisionPRO 7-Day Touchscreen Programmable 3H/2C
TH8110U1003	VisionPRO 7-Day Touchscreen Programmable 1H/1C
TH6220D1028	FocusPRO® 5-1-1 Day Programmable 2H/2C. Large Display
TH6220D1002	FocusPRO 5-1-1 Day Programmable 2H/2C. Standard Display
TH6110D1021	FocusPRO 5-1-1 Day Programmable 1H/1C. Large Display
TH6110D1005	FocusPRO 5-1-1 Day Programmable 1H/1C. Standard Display
TH5220D1029	FocusPRO Non-Programmable 2H/2C. Large Display
TH5220D1003	FocusPRO Non-Programmable 2H/2C. Standard Display
TH5110D1022	FocusPRO Non-Programmable 1H/1C. Large Display
TH5110D1006	FocusPRO Non-Programmable 1H/1C. Standard Display

## Retrofit Round Dampers

Part Number	Description
RRD5	5" Round Damper
RRD6	6" Round Damper
RRD7	7" Round Damper
RRD8	8" Round Damper

## Round Supply Dampers

Part Number	Description
ARD5	5" Round Damper
ARD6	6" Round Damper
ARD7	7" Round Damper
ARD8	8" Round Damper
ARD9	9" Round Damper
ARD10	10" Round Damper
ARD12	12" Round Damper
ARD14	14" Round Damper
ARD16	16" Round Damper
ARD18	18" Round Damper
ARD20	20" Round Damper

## Rectangular Supply Dampers\*

Part Number	Description
ZD10x8	10" Rectangular Damper
ZD12x8	12" Rectangular Damper
ZD14x8	14" Rectangular Damper
ZD16x8	16" Rectangular Damper
ZD18x8	18" Rectangular Damper
ZD20x8	20" Rectangular Damper
ZD20x10	20" Rectangular Damper
ZD24x8	24" Rectangular Damper

\*Available in 125 sizes

Learn more about Honeywell Zoning Solutions for more information about Honeywell Zoning Systems, contact your Honeywell dealer or visit [customer.honeywell.com](http://customer.honeywell.com).

## Learn More

Call toll-free 1-800-328-5111  
or visit <http://yourhome.honeywell.com>  
Email [info@honeywell.com](mailto:info@honeywell.com)

## Automation and Control Solutions

Honeywell  
1985 Douglas Drive North  
Golden Valley, MN 55422-3992  
[www.honeywell.com](http://www.honeywell.com)



# Honeywell

50-9720 RL 10/07  
©2007 Honeywell International Inc.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>