

RCA QuickStartGuide



EZ3100 Series RCA Small Wonder Camcorder
www.rcaaudiovideo.com

Congratulations on purchasing your new RCA Small Wonder Camcorder.
Please read these instructions for quick tips on using the product.

The User Manual PDF file can also be found in the CD ROM under the User Manuals folder.

1. Content of the box

- Small Wonder Camcorder
- USB cable
- AV cable
- Quick Start Guide
- Carrying pouch
- Wrist strap
- Memory Manager CD rom
- AC/DC adaptor

2. Charging your camcorder


Please charge the battery for at least four hours before first use.

NOTE:
The unit is properly charging when you see the animated charging symbol on the camcorder display. If you do not see this charging symbol, follow these steps:

1. Use the included USB cable to connect the camcorder to the AC/DC power adapter. **OR** you may also connect the camcorder to the computer USB port through USB cable, and make sure the computer is turned on.
2. Press and hold the camcorder power switch to the ON position to initiate charging.



3. General controls




***To reset the camcorder (in case it is not functioning properly):**
Press and hold the On/off switch for more than 10 seconds.

- Delete recordings
- Switch between Photo preview and Video preview modes
- +/- Adjust volume during playback; zoom during record and preview
- </> Skip to previous or next recording; fast rewind or forward


4. Inserting (or removing) memory card

An SD memory card (not included) is recommended for recording.




- **To insert card:** Push the card in until a click is heard
- **To remove card:** Push card in until a click is heard, then slowly release the card. As card is under minimal tension when locked in memory slot, please use care when removing.

5. Turning on the camcorder




There are three basic modes for operating the camcorder: Video preview mode, Photo preview mode and Playback mode. It will always launch in video preview mode after being switched on. Refer to the diagram below for switching between modes.



¹ In Video preview mode, press **RECORD** to record a video
² In Photo preview mode, press **RECORD** to record a photo

6. Selecting recording quality




Settings	Resolutions (pixel) & Frame Rates (FPS)	Approx. recording durations on a 32 GB memory card ²
HD	1440 x 1080 @ 30fps	Up to 10 hours
Sports mode	848 x 480 @ 60 fps	Up to 16 hours
WebQ	320 x 240 @ 30 fps	Up to 80 hours


² Actual recording time and capacity will vary depending on type of video content being recorded, system requirements, and other factors.

You can set video quality settings from the Setup Menu. Refer to Recording Videos section in User Manual for more information.


7. Video recording and photo taking




- 1 Start and stop recording in Video preview mode; enter Video preview mode from other modes
- 2 Pause and resume recording
- 3 Zoom in during recording
- 4 Zoom out during recording
- 5 Switch between Video preview mode or Photo preview mode



8. Playing back or deleting recordings



- 1 Enter Playback mode to play the most recent recording; start or pause playback
- 2 Adjust volume during playback
- 3 Cue to previous recording
- 4 Cue to next recording
- 5 Stop playback or enter Video preview mode from playback mode
- 6 Press to select delete one or all recordings.
- 7 When video playback stops, enter Video preview mode from Playback mode



QuickTime and the QuickTime logo are trademarks or registered trademarks of Apple Computer, Inc., used under license therefrom.

Download from www.somanuals.com. All Manuals Search And Download.

9. Installing RCA Memory Manager application

Connect the camcorder to your PC with the provided USB cable. Place the supplied CD-ROM in the CD-ROM tray.

To install Memory Manager 3

Windows: To access the Memory Manager 3 installer, go to **My Computer** (XP users) /go to **Computer** (Vista and 7 users) in the Start menu, find and open the drive letter associated with the CD rom and then double-click the **MemoryMgr3_Windows_Installer.exe** file to launch the installer. The RCA Detective application is installed with Memory Manager 3 and will automatically run the Memory Manager 3 application when your camcorder is connected to the PC.

Mac:

To access the Memory Manager 3 installer, double-click the CD rom volume. Double-click the **RCAMacInstallers.dmg** disk image in the CD rom volume. Locate the **RCAMacInstallers** volume on the desktop and Double-click on it. Double-click the **RCA Memory Manager Installer** file in the **RCAMacInstallers** volume to start the installation.

After the Memory Manager 3 installation has completed, double-click the **RCA Detective Installer** file in the **RCAMacInstallers** volume to install the RCA Detective application, which will automatically run the Memory Manager 3 application when your camcorder is connected to the Mac.

To ensure that videos can be managed and played on your PC:

- Make sure to install the included Memory Manager application.

10. Learning more about the camcorder

Read the user manual for more information on the following:

- Using the button to setup the camcorder (including date and time)
- Viewing videos on TV
- Recording videos to VHS tape or DVD
- Connecting the camcorder to your PC
- Tips and troubleshooting
- Safety and warranty information

Product registration

Thank you for purchasing an RCA product. We pride ourselves on the quality and reliability of all our electronic products but if you ever need service or have a question, our customer service staff stands ready to help. Contact us at www.rcaaudiovideo.com

PURCHASE REGISTRATION: Registering On-line will allow us to contact you in the unlikely event a safety notification is required under the Federal Consumer Safety Act.

Register Online at:
[WWW.RCAAUDIOVIDEO.COM](http://www.rcaaudiovideo.com)
Click on Product Registration and Fill Out the Brief Questionnaire

RCA

12 Month Limited Warranty
Applies to RCA Camcorders

AUDIOVOX ACCESSORIES CORP. (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair labor.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, loss/interruptions of broadcast or internet service, to costs incurred for installation, removal or reinstallation of product, to corruptions caused by computer viruses, spyware or other malware, to loss of media, files, data or content, or to damage to tapes, discs, removable memory devices or cards, speakers, accessories, computers, computer peripherals, other media players, home networks or vehicle electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Visit <http://store.audiovox.com> to find the best accessories for your products.
For Customer Service Visit Our Website At www.rcaaudiovideo.com
Product Information, Photos, FAQ's, User Manual

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>