



MCS*E Series Master Power Supply



C655M-A (1/07)

Important Safety Instructions

Observe the following WARNINGS before installing and using this product.

1. Installation and servicing should be done by qualified service personnel only and conform to all local codes.
2. Unless the unit is specifically marked as a NEMA Type 3, 3R, 3S, 4, 4X, 6, or 6P enclosure, it is designed for indoor use only and must not be installed where exposed to rain and moisture.
3. Only use replacement parts Pelco recommends.
4. After replacing/repairing this unit's electrical components, conduct a resistance measurement between line and exposed parts to verify the exposed parts have not been connected to line circuitry.

The product and/or manual may bear the following marks:



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

CAUTION:
RISK OF ELECTRIC SHOCK.
DO NOT OPEN.

DESCRIPTION

The MCS*E Series consists of multi-output 24 VAC indoor power supplies. These power supplies provide output for 4, 8, or 16 cameras from a single source and come in 2, 5, 10, and 20 amp capacities. The power supplies allow for 120 VAC line input. Higher capacity models can handle pan and tilt and receiver operation, in addition to the camera, for integrated systems such as Spectra® and Esprit®

All MCS*E Series models come with an individual glass fuse for each output channel.

MODELS

Model Number	Outputs	Total Output Current (Amps)	Total Output Power (VA)	Max Current Per Output (Amps)	Max Power Per Output (VA)	Input Current (Amps)	Output Voltage (VAC)	Fuses	Surge Protection	On/Off Switch	Power LED
MCS4-2E	4	2	48	1	24	0.44	24	X	X	X	X
MCS8-5E	8	5	120	3	72	1.1	24	X	X	X	X
MCS16-10E	16	10	240	3	72	2.2	24	X	X	X	X
MCS16-20E	16	20	480	3	72	4.4	24	X	X	X	X

APPLICATION EXAMPLES

Table A contains examples of products and the number of units that can be powered by each power supply, and is based on the VA rating of each product.

Table A. Product Capacity

Product	Power Supply Model			
	MCS4-2E	MCS8-5E	MCS16-10E	MCS16-20E
CDD Camera (12 VA maximum)	4	8	16	16
DF5/DF5S with camera (3 VA)	4	8	16	16
DF8A/PDF8 (12 VA maximum)	4	8	16	16
Indoor Spectra (25 VA)	1	4	8	16
Esprit (70 VA)	—	1	3	6


INSTALLATION

The following items are supplied:

- 1 MCS*E Series Power Supply
- 2 Spare fuses
- 2 Wire nuts

To install an MCS Series power supply, perform the following steps:

1. Decide where to install the unit.
2. Open the lid on the unit by removing the 8-32 Phillips screw.
3. Drill holes in the mounting surface. Use the unit as a template.
4. Attach the unit securely with four fasteners (not supplied) of the appropriate length. You can use fasteners up to 5/16-inch (0.80 cm) in diameter.
5. Punch out the necessary knockouts. (There are six knockout holes on the top and two on the bottom.)
6. Install 1/2-inch (1.27 cm) or 3/4-inch (1.91 cm) conduit fittings where necessary (conduit fittings not provided).

 **WARNING:** Pelco will not be liable for any damages resulting from incorrect wiring or improper loading of an MCS*E Series power supply.

INPUT CONNECTIONS

Table B. Main Fuse Value Table

Fuse Location	MCS4-2E	MCS88-5E	MCS16-10E	MCS16-20E
Main	1A	1.6A	3A	5A
Individual Output	1A	3A	3A	3A

1. Verify that the on/off switch inside the box is OFF.
2. Remove the high voltage compartment panel inside the box.
3. Attach the 120 input wires to the flying leads in the compartment with the supplied wire nuts (brown – AC line; blue – AC neutral).
4. Attach the input ground wire to the stud inside the compartment with the supplied washer and nut.
5. Replace the access panel.

OUTPUT CONNECTIONS

Perform the following steps to attach 24 VAC devices to the MCS*E Series power supply:

1. Refer to Tables C and D in this manual or the wiring table on the unit's lid to determine the output connection needed for your devices.
2. Refer to Figure 1 for the proper connector strip connections.
3. For each device, attach one output wire to the common terminal. Attach the second wire to the appropriate 24 VAC terminal.
4. When you finish the wiring connections, double check the installation for safety purposes.
5. Power up the unit with the on/off switch.
6. Use a voltmeter to verify that used outputs are at appropriate voltage levels.
7. Close the lid and secure it using the 8-32 Phillips screw.




Figure 1. MCS*E Series Unit Wiring Connector Diagram

Table C. Recommended Wiring Distances

The following are the recommended maximum distances (transformer to load) and are calculated with a 10-percent voltage drop. (Ten percent is generally the maximum allowable voltage drop for AC-powered devices.) Distances are calculated in feet; values in parentheses are meters.

Input Voltage	Total VA Consumed	Wire Gauge		
		20	18	16
24 VAC	10	283 (86)	451 (137)	716 (218)
	20	141 (42)	225 (68)	358 (109)
	30	94 (28)	150 (45)	238 (72)
	50	56 (17)	90 (27)	143 (43)

You can use Table D as a guide to determine the necessary wire gauge (AWG) for various cable distances that provide 24 VAC power. Or use it in a reverse fashion to determine the maximum allowable cable distance for a particular wire gauge. Table D applies when using 2-conductor copper wire, with characteristics similar to West Penn 221-227 unshielded cable. Calculations are based on a 10-percent voltage drop (generally the maximum allowable drop for AC-powered devices).

The minimum acceptable voltage is calculated as follows:

$$24.0 \text{ VAC} \\ -0.4 (10\%) \\ 21.6 \text{ (Minimum Acceptable Voltage)}$$

The minimum acceptable voltage used to create Table D was 21.6 volts. Therefore, the 24-volt output has an acceptable range from 24 volts down to 21.6 volts.

Table D. Required Wire Gauge

WIRE DIST (feet)	Require Wire Gauge Table (AWG)											
	CCD Camera	PT480 Pan/Tilt	Indoor Spectra	PT570 Pan/Tilt	Esprit Pan/Tilt	14-inch Intercept	CX9000 Receivers	Outdoor Spectra	← Equipment Loads			
	10VA	20VA	30VA	40VA	50VA	60VA	70VA	80VA	90VA	100VA	200VA	
1000	12-14	12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
900	12-14	12	12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
800	12-14	12	12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
700	12-16	12	12	12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
600	12-16	12	12	12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
500	12-16	12-14	12	12	12	N/A	N/A	N/A	N/A	N/A	N/A	N/A
400	12-18	12-14	12	12	12	12	12	N/A	N/A	N/A	N/A	N/A
300	12-18	12-16	12-14	12	12	12	12	12	12	12	N/A	N/A
200	12-20	12-18	12-16	12-14	12-14	12	12	12	12	12	12	N/A
100	12-22	12-20	12-18	12-18	12-16	12-16	12-16	12-14	12-14	12-14	12-14	12

XX-XX

↑

Recommended Wire Gauge (AWG) using 24 VAC
N/A – Distance and load **not** recommended for any wire size between 12-22 (AWG)

MAINTENANCE

There are no user-serviceable parts except for the fuses. If the transformer in the unit does not work properly, the entire power supply needs to be returned to the factory for repair. Refer to the Warranty and Return Information section of this manual for instructions on returning the power supply for repair.

Clean the outer surface of the power supply with a nonabrasive cleaning cloth and anti-static cleaner. Do not use kerosene or similar substances that may damage the surface.

SPECIFICATIONS

MECHANICAL

Cable Entry	Knockouts for either 1/2-inch (1.27 cm) or 3/4-inch (1.91 cm) conduit
Fuse Size	All fuses are 5 x 20 mm

ELECTRICAL

Input Voltage	120 VAC, 60 Hz
Output Voltage	24 VAC
Required Input Current	See <i>Models</i> section
Output Fuse Ratings	
MCS4-2E	1 A*
MCS8-5E	3 A*
MCS16-10E	3 A*
MCS16-20E	3 A*
Input Connectors	Wire nut
Output Connectors	Screw-type barrier strips
Input Wire Size	12-16 gauge solid wire
Output Wire Size	12-22 gauge solid or stranded wire
Recommended Wiring Distances	See Table C

GENERAL

Construction	Steel
Finish	Black polyester powder coat
Environment	Indoor
Operating Temperature	32° to 120°F (0° to 50°C)
Dimensions	4.37" D x 10.86" W x 16.13" H (11.10 x 27.58 x 40.97 cm)
Unit Weight	
MCS4-2E	13.45 lb (6.10 kg)
MCS8-5E	14.70 lb (6.67 kg)
MCS16-10E	16.60 lb (7.53 kg)
MCS16-20E	19.70 lb (8.94 kg)
Ratings	Meets NEMA Type 1 standards

*Individual output cannot exceed this rating, and the total of all outputs cannot exceed the overall rating of the power supply (see the models section)

(Design and product specifications subject to change without notice.)

PRODUCT WARRANTY AND RETURN INFORMATION

WARRANTY

Pelco will repair or replace, without charge, any merchandise proved defective in material or workmanship **for a period of one year** after the date of shipment.

Exceptions to this warranty are as noted below:

- Five years on fiber optic products and TW3000 Series unshielded twisted pair transmission products.
- Three years on Spectra® IV products.
- Three years on Genex® Series products (multiplexers, server, and keyboard).
- Three years on Camclosure® and fixed camera models, except the CC3701H-2, CC3701H-2X, CC3751H-2, CC3651H-2X, MC3651H-2, and MC3651H-2X camera models, which have a five-year warranty.
- Three years on PMCL200/300/400 Series LCD monitors.
- Two years on standard motorized or fixed focal length lenses.
- Two years on Legacy®, CM6700/CM6800/CM9700 Series matrix, and DF5/DF8 Series fixed dome products.
- Two years on Spectra III™, Esprit®, ExSite™, and PS20 scanners, including when used in continuous motion applications.
- Two years on Esprit and WW5700 Series window wiper (excluding wiper blades).
- Two years (except lamp and color wheel) on Digital Light Processing (DLP®) displays. The lamp and color wheel will be covered for a period of 90 days. The air filter is not covered under warranty.
- Eighteen months on DX Series digital video recorders, NVR300 Series network video recorders, and Endura™ Series distributed network-based video products.
- One year (except video heads) on video cassette recorders (VCRs). Video heads will be covered for a period of six months.
- Six months on all pan and tilts, scanners or preset lenses used in continuous motion applications (that is, preset scan, tour and auto scan modes).

Pelco will warrant all replacement parts and repairs for 90 days from the date of Pelco shipment. All goods requiring warranty repair shall be sent freight prepaid to Pelco, Clovis, California. Repairs made necessary by reason of misuse, alteration, normal wear, or accident are not covered under this warranty.

Pelco assumes no risk and shall be subject to no liability for damages or loss resulting from the specific use or application made of the Products. Pelco's liability for any claim, whether based on breach of contract, negligence, infringement of any rights of any party or product liability, relating to the Products shall not exceed the price paid by the Dealer to Pelco for such Products. In no event will Pelco be liable for any special, incidental or consequential damages (including loss of use, loss of profit and claims of third parties) however caused, whether by the negligence of Pelco or otherwise.

The above warranty provides the Dealer with specific legal rights. The Dealer may also have additional rights, which are subject to variation from state to state.

If a warranty repair is required, the Dealer must contact Pelco at (800) 289-9100 or (559) 292-1981 to obtain a Repair Authorization number (RA), and provide the following information:

1. Model and serial number
2. Date of shipment, P.O. number, Sales Order number, or Pelco invoice number
3. Details of the defect or problem

If there is a dispute regarding the warranty of a product which does not fall under the warranty conditions stated above, please include a written explanation with the product when returned.

Method of return shipment shall be the same or equal to the method by which the item was received by Pelco.

RETURNS

In order to expedite parts returned to the factory for repair or credit, please call the factory at (800) 289-9100 or (559) 292-1981 to obtain an authorization number (CA number if returned for credit, and RA number if returned for repair).

All merchandise returned for credit may be subject to a 20% restocking and refurbishing charge.

Goods returned for repair or credit should be clearly identified with the assigned CA or RA number and freight should be prepaid. Ship to the appropriate address below.

If you are located within the continental U.S., Alaska, Hawaii or Puerto Rico, send goods to:

Service Department
Pelco
3500 Pelco Way
Clovis, CA 93612-5699


If you are located outside the continental U.S., Alaska, Hawaii or Puerto Rico and are instructed to return goods to the USA, you may do one of the following:

If the goods are to be sent by a COURIER SERVICE, send the goods to:

Pelco
3500 Pelco Way
Clovis, CA 93612-5699 USA

If the goods are to be sent by a FREIGHT FORWARDER, send the goods to:

Pelco c/o Expeditors
473 Eccles Avenue
South San Francisco, CA 94080 USA
Phone: 650-737-1700
Fax: 650-737-0933

 The materials used in the manufacture of this document and its components are compliant to the requirements of Directive 2002/95/EC.



This equipment contains electrical or electronic components that must be recycled properly to comply with Directive 2002/96/EC of the European Union regarding the disposal of waste electrical and electronic equipment (WEEE). Contact your local dealer for procedures for recycling this equipment.

REVISION HISTORY

Manual #	Date	Comments
C655M	6/99	Original version.
C655M-A	1/07	Updated Table A VA ratings for Spectra and Esprit. Added operating temperature. Reformatted document.

Pelco, the Pelco logo, Camclosure, Esprit, ExSite, Genex, Legacy, and Spectra are registered trademarks of Pelco. Endura, and Spectra III are trademarks of Pelco. DLP is a registered trademark of Texas Instruments, Inc.

©Copyright 2007, Pelco. All rights reserved.



Worldwide Headquarters
3500 Pelco Way
Clovis, California 93612 USA

USA & Canada
Tel: 800/289-9100
Fax: 800/289-9150

International
Tel: 1-559/292-1981
Fax: 1-559/348-1120

www.pelco.com

ISO9001

Australia | Canada | Finland | France | Germany | Italy | Macau | The Netherlands | Russia | Singapore
South Africa | Spain | Sweden | United Arab Emirates | United Kingdom | United States

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>